

AP Commands

Overview

APs can be configured either before or after deployment, via direct or indirect connectivity.

- **Direct attachment**—The AP is physically plugged into the Aruba controller. As such, power and Serial over Ethernet (SOE) are provided. SOE technology uses spare cable pairs in a standard CAT5 cable to carry RS-232 serial communication.
- **Indirect attachment**—The AP physically plugs into some other network device (such as a controller or router) with Layer2 or Layer 3 connectivity back to the Aruba controller. In this case, power over Ethernet is available if the network device attached to the AP supports it. SOE, however, is not provided in this scenario.

The commands in this chapter require SOE connectivity between the Aruba controller and the AP. Use guidelines in this chapter to determine the AP models eligible for this connectivity, and to access and use the AP commands, as described in the following topics:

- "APs and SoE Connectivity" on page 2
- "Accessing AP Commands" on page 3
- "AP Advanced Commands" on page 5
- "Resetting AP Factory Defaults" on page 13
- "AP Command Help" on page 15

WARNING: AP Commands are 'advanced' commands intended only for use by qualified service personnel. For any function listed in this chapter, you are advised to use the ArubaOS web UI as your method of deployment.

APs and SoE Connectivity

Use commands in this chapter when setting Aruba AP configurations with SOE connectivity. The Aruba APs compatible with SOE connectivity are listed in Table 1.

TABLE 1 Aruba AP SOE Compatibility

SOE Capable	Not SOE Capable
■ AP 52	■ AP 40
■ AP 70	■ AP 41
■ AP 65	■ AP 80
■ AP 60	
■ AP 61	

NOTE: To modify AP configurations for the AP models that do not enable SOE connectivity, it is necessary to physically reset the AP, then set configurations via the controller. Refer to the Installation Guide associated with a specific Aruba AP to obtain more information.

NOTE: Aruba Networks advises that you restrict use of the AP commands to those described in this chapter, and identified in Table 2.

TABLE 2 AP Command Sets

Advanced AP Commands		Factory Reset AP Commands	AP Command Help
■ boot	■ printenv	■ purgeenv	■ help
■ dhcp	■ setenv	■ reset	
■ flash	■ version		
■ ping	■ saveenv		

Accessing AP Commands

Use the procedure in Table 3 to connect to an access point over SOE.

TABLE 3 Connecting to an Access Point Over SOE

Task	Example
1. Start an SSH session to the controller.	<pre>ssh serial@<controller_IP></pre> <p>Using username "serial".</p> <p>serial@al5k's password:</p>
2. At the password prompt, use admin password, then wait for the controller prompt for your login information.	<pre>serial@al5k's password: admin</pre> <p>Entering character mode</p> <p>Escape character is '^]' .</p>
3. At the controller prompt, enter your user name (admin) and password (admin).	<pre>User: admin</pre> <pre>Password: ****</pre> <pre>exit</pre> <pre>soe></pre>
4. At the SOE command prompt, connect to the previously specified slot/port.	<pre>soe> connect 2/12</pre> <p>Connecting to 2/12 at 9600 baud 8N1</p> <p>Type "~." to disconnect</p>
5. Reboot the AP.	<p>Use either of the following methods:</p> <ul style="list-style-type: none"> ■ POE (Power-over-Ethernet) attachment: Unplug the AP Ethernet cable, then plug it back into the AP. ■ Indirect attachment: Unplug the AP power cord from the power source, then plug it back into the power source.

TABLE 3 Connecting to an Access Point Over SOE (Continued)

Task	Example
6.	<p>Wait for the reboot instruction that allows you to halt the reboot now in progress:</p> <p>Hit <Enter> to stop autoboot:</p> <p>then immediately press the Enter key to access APboot mode. Three seconds are (by default) allocated as wait-time for stopping the reboot script and entering APboot command mode. To change this setting, see <code>setenv bootdelay</code>.</p> <pre> APBoot 1.3.12 (build 9066) Built: 2004-11-22 19:28:13 (with gcc 3.3.1) CPU: RC32434 MIPS-32 at 266 MHz: 8 kB I-Cache 8 kB D-Cache Board: Muscat Local Bus at 133 MHz DRAM: 32 MB POST: passed FLASH: 4 MB PCI: scanning bus0 ... dev fn venID devID class rev MBAR0 MBAR1 MBAR2 MBAR3 0a 00 100b 0020 000002 00 000fff01 07fff000 00000000 00000000 0b 00 1106 3038 00000c 61 00000000 00000000 00000000 00000000 000ffe 0b 01 1106 3038 00000c 61 00000000 00000000 00000000 00000000 000ffe 0b 02 1106 3104 00000c 63 07ffef00 00000000 00000000 00000000 0c 00 168c 0013 000002 01 07fe0000 00000000 00000000 00000000 0d 00 168c 0013 000002 01 07fd0000 00000000 00000000 00000000 Net: en0 en1 br0 lo0 Bridg: en0 en1 Hit <Enter> to stop autoboot: 0 apboot> </pre>
7.	<p>You can now use the APboot commands described in this chapter.</p>

You can now use the commands described in this chapter. This mode is also necessary if you need to access APboot command mode to reset default values for an AP. (see also Table 4 on page 13).

AP Advanced Commands

boot

boot—command details

Description	Boot the AP, using currently saved environmental variables. Any unsaved changes to the variables will be lost.
Command Mode	APboot
License Req	not applicable
Syntax	boot [ap elf flash]
	<i>ap</i> Boot from the AP configuration.
	<i>elf</i> Boot from elf files.
	<i>flash</i> Boot from the flash drive.
Example	Booting from the AP. apboot> boot ap

dhcp

dhcp—command details

Description	Invoke DHCP client to obtain IP/boot parameters.
Command Mode	APboot
License Req	not applicable
Syntax	dhcp
Example	Viewing DHCP information from the AP. apboot> dhcp BOOTP broadcast 1 DHCP IP address: 10.4.21.241 DHCP subnet mask: 255.255.255.0 DHCP def gateway: 10.4.21.254 DHCP DNS server: 10.4.21.251 DHCP DNS domain: 200-1800-2.com

flash

flash—command details

Description	Upgrade the boot image. NOTE: Exercise extreme caution when using this command.
Command Mode	APboot
License Req	not applicable

AP Commands

flash—command details (Continued)

Syntax **flash write start** ((end addr) | [[host:]file])
flash erase start end

Example Upgrading the boot image on AP60.

```
apboot> flash write 0xbfc00000  
tftp-server-ip:bootImageFileName
```

ping

ping—command details

Description Check network connectivity.

Command Mode APboot

License Req not applicable

Syntax **ping** [-Rdnqrv] [-c count] [-i wait] [-s size] host

-Rdnqrv ?????

-c count Value to define number of times to repeat the ping.

-i wait Value to define number of milliseconds allowed between packet sends.

-s size Value to define data size: total size of payload allowed for outgoing packets in this ping session.

Example NEED ENGINEERING EXAMPLE

this place reserved for example

printenv

printenv—command details

Description List the environment variables and their current settings. AP boot environmental variables are configured with the APboot setenv command.

NOTE: As of ArubaOS Release 2.2.1, the following conventions apply to the AP images:

- After an AP loads a local image, it compares the image to the booted image.
- If the images differ, the AP attempts to download the latest image via FTP.
- If FTP fails, the AP attempts to download the latest image using TFTP.

Command Mode APboot

printenv—command details (Continued)**License Req** not applicable**Syntax** **printenv****Example** Viewing the current environmental variables running on the AP.

```

apboot> printenv
boardname=Muscat
autostart=yes
baudrate=9600
bootdelay=2
bootfile=mips.ari
ethaddr=00:0b:86:c4:00:ee
enetlmode=active-standby
servername=aruba-master
serverip=10.4.21.1
master=10.4.21.1
a_ant_gain=6caf067648854a44c3a5d4acfa3731752261846600002x002
g_ant_gain=6d9a7b5f9712a86ebd38c365912ac3e22261846600004x002
ap70_ext_ant=1
location=1.3.3
a_antenna=0
g_antenna=0
bootcmd=boot ap

```

Environment size: 378/8186 bytes

apboot>

setenv

setenv—command details

Description Modify configuration of a specified environmental variable.

If no value is set for setenv, the AP will use the factory default for its setenv configuration.

NOTE: Certain environmental variables should remain unchanged unless otherwise advised by Aruba Technical Support. Refer to the Environmental Presets, below, for guidelines.

Environmental Presets Aruba Networks advises that the following variables be retained at default values unless otherwise recommended by Aruba Technical Support.

- autostart: default = yes
- baudrate: default = 9600
- bootcmd: default = localflash
- bootfile: default = sap.bin
This is the file name of the AP image.
- ethaddr: unique for each AP.
This is the MAC address of the Ethernet interface on the AP.
- stderr: default = serial
- stdin: default = serial
- stdout: default = serial

License Req not applicable

Command Mode APboot

Syntax **setenv** <environment var> <value>

environment var Type of environment to set:

- bootdelay (See setenv bootdelay)
- location (See setenv location)
- master (See setenv master)
- servername (See setenv servername)
- serverip (See setenv serverip)
- ipaddr (See setenv ipaddr)
- netmask (See setenv netmask)
- gatewayip (See setenv gatewayip)

setenv bootdelay

setenv bootdelay—command details

Description	Length of time, in seconds, to define the autoboot timer. This sets the delay during which the currently logged in user can interrupt the boot process and access the apboot prompt.
Command Mode	APboot
License Req	not applicable
Syntax	setenv bootdelay <val> <i>val</i> Number of seconds to define the boot delay duration.
	Default: 3
Example	Setting a new boot delay time. apboot> setenv bootdelay 5

setenv location

setenv location—command details

Description	Set the physical, permanent location of the AP. The location identifier contains the building number, floor number, and device number separated by dots. The location specifies which configuration profile is to be downloaded to the AP from the WLAN controller.
Command Mode	APboot
License Req	not applicable
Syntax	setenv location <building number>, <floor number>, <device number> Default: 1.1.1 (unconfigured)
<i>building number</i>	Building number, as a value in the range 1 to 255.
<i>floor number</i>	Floor number, as a value in the range 1 to 255.
<i>device number</i>	AP assigned number.
Example	Setting location information that specified the AP in building 3, floor 4, device number 2 apboot> setenv location 3.4.2

setenv master**setenv master—command details**

Description	Set IP address or hostname of the Mobility Controller that controls the AP. The AP downloads its configuration from the specified switch. If a hostname is specified, your DNS server must be configured to resolve the hostname to the master Mobility Controller. This setting overrides the value of serverip and servername
Command Mode	APboot
License Req	not applicable
Syntax	setenv master <ip address hostname>
Example	Defining the master controller, using IP address 1.1.2.1 apboot> setenv master 1.1.2.1

setenv servername**setenv servername—command details**

Description	Set hostname of the Mobility Controller for TFTP server that holds the AP software image and/or configuration files. When using this variable, your DNS server must be configured to resolve the specified hostname to the appropriate location. This setting overrides the value of serverip (for both software and configuration) and is overridden by the master variable (for configuration only) if configured.
	Default: aruba-master
Command Mode	APboot
License Req	not applicable
Syntax	setenv servername <hostname
	<i>hostname</i> Name of the DNS server to bind to this configuration.
Example	Setting a new TFTP source for downloading the software and/or configuration files. This example demonstrates setup of TFTP server named <i>mytftp</i> , to enable accessed by the AP. After setting the servername , the configuration is saved using the saveenv command, then verified by using the printenv command. apboot> setenv servername mytftp NOTE: After setting the server name, use the saveenv command to save your settings, then use the printenv command to verify your entries.

setenv serverip

setenv serverip—command details

Description IP address of the Mobility Controller or TFTP server where the AP software and/or configuration files are stored.

NOTE: This setting is typically only if DNS is not used.

Setenv serverip is overridden by the servername variable (for both software and configuration) and the **master** variable (for configuration only) if configured.

Command Mode APboot

License Req not applicable

Syntax **setenv serverip** <ipaddress>

Example Defining the locator of the AP software and configuration files for the Mobility controller server

```
apboot> setenv serverip 1.2.1.0
```

setenv ipaddr

setenv ipaddr—command details

Description IPv4 address of the AP. If the IP address is defined with **setenv ipaddr**, the AP will use this address rather than obtaining an IP address via DHCP.

Command Mode APboot

License Req not applicable

Syntax **setenv ipaddr** <ipaddress>

Example Setting 10.1.2.1 as the default environment.

```
apboot> setenv ipaddr 10.1.2.1
```

setenv netmask

setenv netmask—command details

Description IP address mask of the AP. This setting is used in conjunction with the ipaddr variable to define the subnet of the AP.

Command Mode APboot

License Req not applicable

Syntax **setenv netmask** <ipaddress>

Example Setting the netmask for the AP as 255.255.255.0

```
apboot> setenv netmask 255.255.255.0
```

AP Commands

setenv gatewayip

setenv gatewayip—command details

Description	IP address of the default gateway. This setting is used in conjunction with the configured ipaddr when using static addresses instead of DHCP.
Command Mode	APboot
License Req	not applicable
Syntax	setenv gatewayip <ipaddress>
Example	Setting the default gateway as 10.0.0.1 apboot> setenv gatewayip 10.0.0.1

version

version—command details

Description	View current AP boot build information.
Command Mode	APboot
License Req	not applicable
Syntax	version
Example	Displaying version information for the AP associated with this login session. apboot> version APBoot 1.3.12 (build 9066) Built: 2004-11-22 19:28:13 (with gcc 3.3.1) apboot>

Resetting AP Factory Defaults

Use guidelines in this section to reset factory defaults for an AP, using AP Boot commands. Resetting an AP requires that you initiate a reboot of the AP but halt the reboot in progress to enable access to the APboot commands. See Table 4 on page 13 to find out how to access the apboot prompt, which enables access to APboot commands.

TABLE 4 Resetting AP Factory Defaults

Task	Description
1. Power cycle the AP.	
2. Use the procedure in Table 4 on page 13 to access the AP boot commands.	AP Boot commands are available when you see the apboot prompt on the screen.
3. Purge the existing AP configuration.	apboot> purgeenv Erasing... Programming... Verifying...
4. Save the AP configuration	apboot> saveenv Erasing... Programming... Verifying...
5. Reset the AP.	apboot> reset

purgeenv

purgeenv—command details

Description	Reinstate AP boot configuration factory default.
Command Mode	APboot
License Req	not applicable
Syntax	purgeenv <purgeenv purge>
	<i>purgeenv</i> ????
	<i>purge</i> ????
Example	NEED ENGINEERING EXAMPLE
	apboot> purgeenv