Wired Policy Enforcement



a Hewlett Packard Enterprise company

ClearPass

Copyright

Copyright © 2017 Hewlett Packard Enterprise Development LP.

Change Log

Version	Date	Modified By	Comments
2018-01	2/9/18	Tim Cappalli Aruba Security Group	 MAJOR CHANGES [CW7] Added ClearPass OnConnect section [CW7] Updated dynamic authorization references to use new H3C templates in 6.7 MINOR CHANGES [AOS-S] corrected ordering of some commands [AOS-S] added addr-limit config [AOS-S] added SNMP server trap source [AOS-S] updated DUR section to include standard mode added in 6.7 [AOS-S] updated web auth service to use new page name attribute added in 6.7 [Cisco] Added note about LAN base image [Cisco] updated web auth service to use new page name attribute added in 6.7 [CW7] updated web auth service to use new page name attribute added in 6.7
2017-02	7/31/17	Tim Cappalli Aruba Security Group	Added ArubaOS-Switch 16.04 features (downloadable user roles and per-user tunneled-node)
2017-01 (1.0)	6/2/17	Tim Cappalli Aruba Security Group	Initial release. ArubaOS-Switch 16.02, Comware 7, Cisco IOS 12/15 w/ IBNS1

Contents

The Building Blocks for Secure Access	3
Technologies and Components	4
Standards and Technologies	4
Switch Requirements for Colorless Ports	6
Enforcement Options	7
RADIUS-based Enforcement	8
Centralized RADIUS-based Enforcement with Per-Port Tunneled-Node	11
Dynamic RADIUS-based Enforcement with Per-User Tunneled-Node	12
SNMP-based Enforcement with ClearPass OnConnect	13
Policy Enforcement Configuration	15
ArubaOS-Switch Enforcement	15
RADIUS-based Enforcement	15
SNMP-based Enforcement	47
Per-Port Tunneled-Node (PPTN)	57
Per-User Tunneled-Node (PUTN)	84
HPE FlexNetwork (Comware v7) Enforcement	90
RADIUS-based Enforcement	90
SNMP-based Enforcement	115
Cisco Catalyst (IOS) Enforcement	125
RADIUS-based Enforcement	125
SNMP-hased Enforcement	150

The Building Blocks for Secure Access

There are four fundamental elements for building a secure, dynamic wired edge: Profiling, Authentication, Authorization and Posture.

Profiling

Understanding which devices are connecting to the network and what each of their capabilities are is critical to building a secure network policy. For example, Windows, macOS and most Linux distros have robust and flexible 802.1X supplicants that support secure user and device authentication, whereas most printers, media players, building controls, sensors and other headless devices do not support any interactive authentication methods.

Device profile information is also important for detecting unauthorized access to the network. If a user were to change the MAC address of their laptop to match a previously authenticated device, like a printer, for example, ClearPass will detect a profile change and trigger a conflict state.

Authentication

User and/or device identification enables dynamic network policies based on properties such as group, department, organizational structure, or owner. Authentication solutions can range from simplistic to complex, but flexible enough to meet the needs of an organization's security policy.

Authorization

The authorization phase is where most of the magic happens, regardless of the authentication method. Contextual information from all corners of the network and infrastructure can be evaluated to help make a policy decision. Some examples of contextual data sources include the user identity store, enterprise mobility management solutions, endpoint security solutions, asset management tools, the ClearPass device profile information, as well as nearly anything that has a SQL or API-based interface. The possibilities are endless and allow for robust, dynamic network security policies.

Posture

Posture can mean many different things in different environments. In a traditional "NAC" sense of the word, posture often refers to device health using some form of agent, whether persistent, dissolvable or embedded. This agent validates a predefined health policy that is used as part of authorization for network access. As more and more organizations deploy Enterprise Mobility Management (EMM) solutions for both corporate and personal assets, posture has evolved to included device data from these solutions.

In environments where traditional health status is not required for security or business requirements, profiling data can be viewed as a type of posture for the device. For example, a device that starts as a printer and becomes a Mac laptop creates a conflict condition which indicates some type of device posture change.

Technologies and Components

Standards and Technologies

802.1X

802.1X is a framework for port-based access control which is most commonly used with 802.3 Ethernet networks and 802.11 wireless LANs. There are three entities: supplicant (client device), authenticator (network device), and the authentication server (commonly a RADIUS server).

Additional information: http://www.ieee802.org/1/pages/802.1x-2010.html

EAP

EAP is the Extensible Authentication Protocol and is a framework for various authentication methods (known as EAP methods). EAP operates as part of the 802.1X framework at layer 2 prior to IP address assignment.

Additional information: https://tools.ietf.org/html/rfc3748

Common EAP Methods

There are over 40 EAP methods in the wild but the most popular and widely supported methods are EAP-TLS, PEAP and EAP-TTLS.

EAP-TLS (Transport Layer Security) is the gold standard in network authentication and uses mutual authentication with both server and client certificates. EAP-TLS is recommended for secure network authentication.

Additional information: https://tools.ietf.org/html/rfc5216

PEAP (Protected EAP) encapsulates other EAP methods inside a TLS tunnel and uses a server-side certificate for authentication server validation by the supplicant. Common inner methods include EAP-MSCHAPv2 and EAP-GTC. Due to wide OS supplicant support, PEAPv0/EAP-MSCHAPv2 is the most widely used EAP method but suffers from security issues related to man-in-the-middle attacks when the supplicant is not preconfigured.

Additional information: https://tools.ietf.org/html/draft-kamath-pppext-peapv0-00

EAP-TTLS (Tunneled Transport Layer Security) is similar to PEAP and uses a server side certificate with supplicant validation. This EAP method is commonly used in non-Active Directory environments where username/password based authentication is desired. EAP-TTLS is supported on a wide range of platforms but may require an administrative configuration profile and/or manual configuration which can add to deployment overhead and complexity. The EAP method also suffers from the same man-in-the-middle attack concerns as PEAP with a supplicant that is not pre-configured.

Additional information: https://tools.ietf.org/html/rfc5281

RADIUS

The RADIUS protocol is used for Authentication, Authorization and Accounting (AAA) communication between authenticators (network access devices) and the authentication server (RADIUS server). Attribute Value Pairs (AVPs) are used to pass information between the authenticator and authentication server in both directions.

EAP messages are encapsulated in RADIUS packets between the authenticator (network device) and the authentication server (RADIUS server).

Additional information: https://tools.ietf.org/html/rfc2138

SNMP

Simple Network Management Protocol is most commonly used for monitoring devices but can also be used for setting configuration elements on the device.

SNMP traps are used to notify a management/monitoring platform of an event, similar to a push notification.

Additional information: http://www.snmp.com/protocol/

Switch Requirements for Colorless Ports

ClearPass is a multi-vendor product that leverages standards-based protocols and technologies along with the flexibility to support vendor-specific switch features for policy enforcement. Below are the basic switch feature sets required for various policy enforcement workflows. These technologies and features will be discussed throughout this document.

RADIUS-based Enforcement

Feature	Role	Primary Use
802.1X IEEE-802.1X	Secure port access via EAPoL	Standard AAA
MAC Authentication Bypass	Fallback for headless devices and guests	Standard AAA, Guest
Dynamic Authorization RFC 5176 (replaced RFC 3576)	Session lifecycle: change of user or device posture/behavior/status	Standard AAA, Guest, Onboard, OnGuard
External Captive Portal Redirect	Guest registration and login, device onboarding, informational splash pages	Guest, Onboard, OnGuard

SNMP-based Enforcement


Feature	Role
SNMP Trap: Link Status	Informs ClearPass of a link state change to trigger policy evaluation
SNMP Trap: MAC Notification	Informs ClearPass of the MAC address(es) detected on the port for use in policy evaluation.
SNMP Write: VLAN	Provides the ability for ClearPass to enforce VLAN assignment based on policy evaluation

NOTE: These are the base level requirements for SNMP-based enforcement on the switch side. ClearPass OnConnect must also support the switch. As of ClearPass 6.7.0, OnConnect currently supports ArubaOS-Switch, HPE FlexNetwork (Comware 7) and Cisco Catalyst switches.

Enforcement Options

There are many different ways to enforce policy on the wired edge. ClearPass offers the capability to enforce policy using standards-based technologies which allow for robust, multi-vendor policy creation and enforcement.

The diagram below offers a 10,000-foot view of the different enforcement methodologies and how they compare from a network security versus a switch configuration complexity point of view. As will be explained throughout this document, many of these are layered together to form the golden colorless port.



RADIUS-based Enforcement


Often times "enabling AAA on the switch" is equated with 802.1X, but that's not the case. AAA can mean 802.1X, MAC Authentication, web authentication or any combination depending on the switch's capabilities.

802.1X

The gold framework for secure port-based access control is defined in the 802.1X standard. The framework offers the best possible mix of flexibility, security, user and device identification and dynamic policy changes.

EAP-based authentication is used within the 802.1X framework to provide multiple different methods of authenticating to the network. As explained earlier, the three most popular EAP methods are EAP-TLS, PEAP, and EAP-TTLS.

The sequence diagram below is an example of a basic EAP-TLS authentication.




Common examples of wired devices capable of 802.1X authentication:

- Laptops and desktops running:
- Windows
- macOS
- Most Linux distributions
- Newer printers
- VoIP devices
- Aruba access points

MAC Authentication

MAC authentication, sometimes referred to as MAC Auth Bypass (MAB), is commonly used as a fail-through for headless, non-802.1X capable and legacy devices as well as guest users. MAB is often combined with 802.1X and Captive Portal as part of a colorless port configuration supporting every user and device type with a single port configuration.

MAC authentication occurs between the switch and the RADIUS server by sending the client MAC address as the username and either the MAC address or a pre-shared key as the password.



Because MAC Authentication occurs between the switch and the RADIUS server, no client-side configuration or interaction is necessary. Due to this simplicity, MAC authentication is often deployed as a first step in the network authentication journey with the eventual goal of moving to 802.1X. It is then used as a fallback for non-802.1X capable and guest devices.


One thing to be aware of is that MAC addresses can be spoofed. MAC authentication should only be used in combination with other authorization components like device profiling. ClearPass has a built-in "conflict" state that is triggered when the category of a device changes. For example, if a printer is suddenly reprofiled as a computer, there is likely reason for concern.

Common examples of devices authorized using MAC address:

- Building controls (HVAC, door access, etc)
- Game consoles and media players
- IP cameras
- Older printers
- Patient care medical devices

Captive Portal

Web-based authentication using captive portals is often associated with guest networks. Their usage has evolved to include other functions such as device onboarding, multi-factor authentication and splash pages for user notifications.



Centralized Enforcement Using Per-Port Tunneled-Node

For the highest level of security, visibility and control, Aruba switches and Aruba Mobility Controllers can be used together to offer stateful firewall processing, application visibility and bandwidth restrictions, and centralized policy enforcement using the Per-Port Tunneled-Node (PPTN) feature.

Overview

Per-Port Tunneled-Node (PPTN) is a unique feature, introduced in ArubaOS-Switch version 16.02 and supported on Mobility Controllers running ArubaOS 6.5 and higher, which allows for all wired traffic entering a switch port to be GRE encapsulated and sent up to an Aruba Mobility Controller for processing; like the tunnel forwarding mode in the Aruba wireless architecture.

When a port is configured for PPTN, it is placed into a dead-end VLAN locally on the switch. This VLAN must also exist on the controller but cannot be tagged throughout the network. It must match on both sides and cannot have an IP address or be tagged on an interface. This VLAN is used on the inside of the GRE tunnel to transport the traffic between the switch and controller.

Once the tunnel is established, the controller handles all AAA functions and places the device into the appropriate user role. All firewall policies, bandwidth contracts and other traffic restrictions are enforced by the controller. The traffic flow is nearly identical to a wireless client connected to a tunneled SSID.

Sample Use Cases

- Branch scenarios where all wired and wireless traffic is processed by a Mobility Controller
- Regulatory or high-risk environments where all wired traffic must traverse a firewall
- Providing access to a centrally defined network that does not traverse the entire infrastructure
- Areas with high numbers of headless/IoT devices like building infrastructure head-ends or maintenance facilities
- Temporarily providing access during an event using an unmanaged switch

Dynamic Segmentation and Enforcement Using Per-User Tunneled-Node

Overview

Per-User Tunneled-Node (PUTN), introduced with ArubaOS-Switch 16.04 and supported on Mobility Controllers running ArubaOS 8.1 and higher, adds the ability for a ClearPass policy decision to tell an Aruba switch whether a device's traffic should be processed locally or tunneled to a Mobility Controller. This enables stateful firewall processing of traffic and advanced application control at the controller when you need it, and traditional stateless processing at the switch when you don't.

Per-User Tunneled-Node can take advantage of new ArubaOS 8 features such as dynamic load balancing of users in a cluster. Tunneling is enabled in the Aruba user role and can be combined with the Downloadable User Role (DUR) feature for dynamic and flexible policy enforcement and segmentation.

Sample Use Cases

As an example, a typical edge network consists of employee desktops and laptops, visitor or contractor laptops, access points, security cameras, desk and conference phones, building controls and headless meeting room equipment.

Туре	Enforcement	Notes
Access Point	Local	Local infrastructure device
Voice / Video Device	Local	Desk and conference phones, security cameras, room media systems
Employee on Managed Device	Local	Users connecting from a healthy, managed device can stay local to the switch
Employee on Unmanaged Device	Tunnel	Users connecting from an unmanaged, potentially untrusted device can be tunneled
New/Unknown Device	Tunnel	Tunnel new or unknown , potentially untrusted devices for profiling, potential onboarding, guest registration or and/or quarantine
Guest User	Tunnel	Tunnel guest users to DMZ guest network
Contractor	Tunnel	Contractors may need more access than a traditional guest user
Change in User/Device Posture	Tunnel	User or device goes from a healthy to unhealthy state (OnGuard checks, IntroSpect notification, Ingress Event Engine Notification)

SNMP-based Enforcement with ClearPass OnConnect

ClearPass OnConnect is a new feature added in ClearPass 6.6.1 which utilizes SNMP for non-authenticated, basic VLAN enforcement at the edge and is included in the base ClearPass license!

Technical Overview

Profiling

Profiling is a very important piece of OnConnect because there is no traditional authentication phase.

Just like RADIUS-based enforcement, traditional passive profiling data, like DHCP fingerprints, can be leveraged as part of an OnConnect policy evaluation. Active methods such as Enterprise Mobility Management (EMM) platform data can also be leveraged to build policy.

OnConnect also supports a new method of active profiling that leverages the Windows Management Instrumentation (WMI) protocol for domain-joined Windows devices. ClearPass can send a WMI request to the device to request the active logged in user on a Windows domain-joined device. ClearPass can then run an authorization query against Active Directory to pull in directory information about the user such as group membership, OU and department. These directory attributes can then be used as part of an OnConnect enforcement just like in a RADIUS role mapping and/or enforcement policy.


How It Works

Switches are configured to send link change (up/down) and MAC notification SNMP traps to ClearPass. When a new device connects, and the switch has sent the trap(s), Policy Manager will verify that the switch and port have been configured for OnConnect enforcement and then proceed with policy evaluation. Note that during this time, the device will be in the default VLAN as configured on the switch port.

If WMI credentials have been defined in ClearPass, a WMI request will be sent to the client requesting the currently logged in user. If a username is returned and authorization to Active Directory is enabled in the service, Policy Manager will query AD for the user properties. Any additional authorization sources, such as the Endpoint Repository, Guest Device Repository (device registration) or even an external SQL database, will be queried as well.

Three SNMP enforcement actions are available: VLAN Change, Port Bounce, and Session Timer. In many cases, all 3 will be combined as part of an enforcement. For example, if a logged in AD user is detected on the device, you may want to change the VLAN, reset the port (so the device can re-DHCP in the correct VLAN) and also set a session timer to trigger re-authentication at a later time.

In the Policy Enforcement section of this guide, full configuration examples will be provided.



Sample Use Cases

- Legacy switching that lacks reliable 802.1X and/or MAC authentication support
- Varying versions of switch code across the environment
- Existing network/helpdesk support team knowledge, comfort level and expertise with SNMP vs RA-DIUS.

Policy Enforcement Configuration

The remainder of this document will cover configuration of some common scenarios utilizing the technologies discussed earlier.

These examples are just that, examples. They're designed to show different ways to build policy on both the network device and in ClearPass. Not every unique scenario or combination will be covered but the goal is to highlight key concepts and features that can be adapted into other scenarios.

ArubaOS-Switch Enforcement

RADIUS-based Enforcement

Policy Enforcement

Similar to an Aruba wireless controller, ArubaOS-Switch uses the concept of user roles to simplify configuration and policy creation and increase visibility and control.

User Roles

An ArubaOS-Switch user role can contain:

- VLAN-ID or VLAN name
- reauthentication interval
- user policy
- captive portal profile

A user policy is composed of one or more traffic classes to match specified packets. The class defines the ACL to match traffic and the policy combines multiple classes together with enforcement actions.

Here's an example of a complete user role configuration with dependencies:

```
class ipv4 "IP-ANY-ANY"
    match ip 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255
    exit

policy user "PERMIT-ALL"
    class ipv4 "IP-ANY-ANY" action permit
    exit

aaa authorization user-role name "SECURE"
    policy "PERMIT-ALL"
    reauth-period 28800
    vlan-name "EDGE_SECURE"
    exit
```

A user role defined locally on the switch itself is known as a local user role (LUR).

Downloadable User Roles (DURs)

Downloadable user roles (available on Aruba Mobility Controllers, Aruba Mobility Access Switches and ArubaOS-Switches) enable ClearPass to act as a centralized policy and enforcement definition point. This allows an intelligent edge with greater flexibility and dynamic security while simplifying local configuration.


ClearPass has a special enforcement profile template for DUR called **Aruba Downloadable Role Enforcement**. This template supports all 3 Aruba products (ArubaOS-Switch, Mobility Access Switch and Mobility Controller).

Enforcement Profiles Profile **Role Configuration** Summary Template: Aruba Downloadable Role Enforcement ı Name: Description: Type: **RADIUS** Action: Accept Reject Drop Device Group List: Remove View Details Modify --Select-- Standard Advanced Role Configuration Mode: Product: ✓ ArubaOS-Switch Mobility Access Switch Mobility Controller

Two configuration modes are available for Downloadable User Roles, Standard and Advanced.

NOTE: ArubaOS-Switch 16.04+ and ClearPass 6.6.7+ are required to use Downloadable User Roles and standard mode is only available in ClearPass 6.7.0+.

Standard mode uses a GUI editor to build out the role elements like VLAN assignment, classes and policy.




Advanced mode allows for direct input of all required user role configuration elements as the **Value** for the **HPE-CPPM-Role** attribute.



Each DUR has a version number that is automatically generated by ClearPass and dynamically appended to the name in the background. This allows the switch to determine if role elements have changed and download a new version of the role for use with subsequent authentications. This also prevents the switch from downloading the same role for every new device.

When a downloadable user role name is returned in the RADIUS access-accept, the switch checks to see if the DUR + version combination already exists. If present, the switch's cached version of the role is applied to the user. If the role is not present, or if the version number has changed, the switch initiates an HTTP GET to ClearPass to download the updated role elements. Existing authenticated users will continue to use the older role version until they reauthenticate. This process is illustrated in the sequence diagram below.

NOTE: HTTPS (TCP 443) must be permitted between the switch's management IP and ClearPass. The request is sourced from the same interface/IP as RADIUS.



Dynamic Authorization

ArubaOS-Switch supports the following Disconnect and Change of Authorization commands:

- Terminate Session: traditional disconnect message; reinitializes authenticator state
- Bounce Host Port: bounces the port by disabling and re-enabling the port
- Disable Host Port: administratively disables the port
- Change User Role: dynamically change the user role without disconnecting the user

Configuration Overview

Here are the hardware and software combinations used for this configuration:

- Aruba 2930F switch running ArubaOS-Switch 16.04.008
- ClearPass Policy Manager 6.6.7

This configuration has been tested on the Aruba 3810M and 2930F. The minimum version of ArubaOS-Switch required for this configuration is 16.04.008.

Switch Configuration

The configuration snippets below assume that components like VLANs, uplinks, NTP and other basics have already been configured.

Key basic components:

- NTP is required as accurate time plays a critical role in network authentication
- To support captive portal redirection, the client VLAN(s) must have an IP address assigned on the switch (ex: vlan 812 ip address 100.81.2.252/24). It is recommended to use the authorized-managers feature to restrict access to switch management functions on these interfaces.

Enable global functions and configurations:

ip client-tracker trusted	provides IP visibility for AAA- enabled ports
ip source-interface radius vlan 810	set RADIUS source interface

Define the ClearPass server(s) as RADIUS server(s) and dynamic authorization client(s):

radius-server host 100.65.30.42 key Aruba123!	define ClearPass as RADIUS server
radius-server host 100.65.30.42 dyn-authorization	enable dynamic authorization (CoA)
radius-server host 100.65.30.42 time-window plus-or-minus-time-window 30	time difference permitted for CoA packet (seconds)
aaa server-group radius CLEARPASS host 100.65.30.42	assign to server-group

To support downloadable user roles, the signing CA (intermediate) of the ClearPass HTTPS certificate must be added to the switch and marked as trusted.

For example, clearpass-demo.arubaboston.com (server certificate) is signed by COMODO RSA Domain Validation Secure Server CA (intermediate / signing CA) which is signed by COMODO RSA Certification Authority (root CA).

The COMODO RSA Domain Validation Secure Server CA should be added to the switch.

crypto pki ta-profile CLEARPASS	create new trust profile
<pre>copy <sftp tftp> ta-certificate CLEARPASS <sftp tftp server=""> <ca-cert-filename></ca-cert-filename></sftp tftp></sftp tftp></pre>	copy the signing CA certificate to the switch via SFTP or TFTP

DURs also require a ClearPass read-only user account to download the user role configuration. Configure the expected username and password for the account.

radius-server cppm identity aoss-dur key R!!y5tr0ngpw ClearPass DUR account

Enable AAA functions:

aaa authentication port-access eap-radius server- group CLEARPASS	enable EAP-based authentication
aaa authentication mac-based chap-radius server-group CLEARPASS	enabled MAC authentication
aaa accounting network start-stop radius server-group CLEARPASS	enable RADIUS accounting
aaa accounting update periodic 5	set interim-accounting update interval (minutes)
aaa authentication captive-portal enable	enable captive-portal redirect
aaa authorization user-role enable	enable user roles
aaa authorization user-role enable download	enable DUR

Port configuration:

aaa port-access authenticator active	enable port authentication
aaa port-access authenticator 1-12 client-limit 10	permit up to 10 active clients per port
aaa port-access mac-based 1-12	enable MAC authentication on ports 1-12
aaa port-access mac-based 1-12 addr-limit 10	permit up to 10 authenticated MACs per port
aaa port-access authenticator 1-12	enable EAP-based authentication on ports 1-12
aaa port-access authenticator 1-12 supplicant-timeout 10	supplicant timeout period (seconds)
aaa port-access authenticator 1-12 tx-period 10	EAP Request-Identity waiting period (seconds)

Define traffic classes to match packets for use in policy:

```
class ipv4 DNS
match udp any any eq 53

class ipv4 DHCP
match udp any any eq 67

class ipv4 INTERNAL
match ip any 100.64.0.0/10

class ipv4 IP-ANY-ANY
match ip any any

class ipv4 WEB-TRAFFIC
match tcp any any eq 80
match tcp any any eq 443

class ipv4 CLEARPASS-WEB
match tcp any host 100.65.30.42 eq 80
match tcp any host 100.65.30.42 eq 443
```

Create user policies to take action on the traffic classes:

policy user CLEARPASS-REDIRECT	
class ipv4 DNS action permit	permit DNS, DHCP and web traffic destined for
class ipv4 DHCP action permit	ClearPass, redirect all
class ipv4 CLEARPASS-WEB action permit	other web traffic
class ipv4 WEB-TRAFFIC action redirect captive-portal	
policy user DENY-INTERNAL	
class ipv4 DNS action permit	permit DNS and DHCP,
class ipv4 DHCP action permit	deny all internal subnets,
class ipv4 INTERNAL action deny	permit everything else
class ipv4 IP-ANY-ANY action permit	
policy user PERMIT-ALL	normit over thing
class ipv4 IP-ANY-ANY action permit	permit everything

Here are a few examples of user role configurations:

aaa authorization user-role name BYOD policy PERMIT-ALL reauth-period 43200 vlan-name EDGE_GUEST	BYOD role, allow all reauthenticate every 12 hours EDGE_GUEST VLAN
aaa authorization user-role name GUEST policy DENY-INTERNAL reauth-period 14400 vlan-name EDGE_GUEST	GUEST role, deny internal IPs reauthenticate every 4 hours EDGE_GUEST VLAN
aaa authorization user-role name VOICE policy PERMIT-ALL reauth-period 86400 vlan-name EDGE_VOICE	VOICE role, allow all reauthenticate every 24 hours EDGE_VOICE VLAN
aaa authorization user-role name SPLASH captive-portal-profile use-radius-vsa policy CLEARPASS-REDIRECT vlan-name EDGE_GUEST	SPLASH role, redirect to ClearPass Use URL from RADIUS response EDGE_GUEST VLAN This is the "fail through" role
aaa authorization user-role name PROFILE captive-portal-profile use-radius-vsa policy CLEARPASS-REDIRECT reauth-period 180 vlan-name EDGE_GUEST	PROFILE role, redirect to ClearPass Use URL from RADIUS response Reauthenticate every 3 minutes EDGE_GUEST VLAN, this role is used to profile unknown devices.


ClearPass: Basics

ArubaOS-Switch uses the Hewlett-Packard-Enterprise RADIUS dictionary and two new vendor-specific attributes (VSAs) were added to support the local user role and downloadable user role features.


The minimum supported ClearPass release for the downloadable user role feature is 6.6.7 which includes the two new VSAs.

If only local user roles will be used with ClearPass prior to 6.6.7, verify that the Hewlett-Packard-Enter-prise dictionary in your ClearPass cluster has attribute #25, HPE-User-Role. If it's missing, download and import the latest dictionary file from support.arubanetworks.com Download Software > ClearPass > Tools > RADIUS Dictionaries.

Instructions for importing a new or updated RADIUS dictionary can be found in the <u>ClearPass User Guide</u>.



Define your switch(es) as a network device(s) under **Configuration** » **Network** » **Devices**. At a minimum, configure **Name**, **IP** or **Subnet Address**, **RADIUS Shared Secret** and **Vendor Name**.



To utilize the downloadable user role feature, a read-only administrator account must be created in ClearPass so the switch can download the role information. Navigate to **Administration** » **Users and Privileges** » **Admin Users** » **Add**. The username and password should match the account defined on the switch in the previous section. For **Privilege Level**, select **Read-Only Administrator**.



ClearPass: MAC Authentication

Overview

The MAC Authentication service will handle headless devices like printers, phones, access points and others as well as provide the redirect URL for unknown devices and users to allow for a captive portal authentication.


In this scenario, we're leveraging the Guest Device Repository and Device Registration portal to allow endusers and IT staff to register headless and non-802.1X capable devices. These devices can be assigned a role and account lifetime.

Service Configuration

Start with a new service of type MAC Authentication.

Under More Options, check the **Authorization** and **Profile Endpoints** boxes. This will enable two new tabs. The default service rules will work with an ArubaOS-Switch.

If there is a need to restrict the service to a particular set of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS_TO_GROUP** rule to reference a NAD group as seen in rule 4 below.



Authentication

On the authentication tab, remove [MAC Auth] under Authentication Methods and add [Allow All MAC Auth].


For Authentication Sources, you'll add [Guest Device Repository] [Local SQL DB] and move it above [Endpoints Repository] [Local SQL DB].



Authorization

On the Authorization tab, add the [Endpoints Repository], [Guest User Repository] and [Guest Device Repository] to the "Additional authorization sources..." list as shown below.

By default, authorization data is only fetched from the authentication source where the user/device was found.




So, for example, say a guest user's device is re-authenticating to the network within their account expiration window, you'll find the MAC address in the [Endpoints Repository] with some data like guest role and expiration time but we also want to check with ClearPass Guest to make sure an administrator hasn't disabled the account.

Roles

Role mapping is used to tag devices and users with as much information as possible for use in a policy decision. This role map is an example of a typical MAC authentication scenario


- Rule 1 and 2 are checking to see that a guest user account is still valid and returning the [MAC Caching] tag / TIPS role
- Rules 3-12 map user and device role IDs to tags / TIPS roles for use in policy
- Rules 13-15 map profiling data to a tag / TIPS role for use in policy



Enforcement

For the default policy, the captive portal "splash" role is specified. This is used when a request falls through the policy with no match.

Let's take apart the enforcement rules one by one:



(Authorization:[Endpoints Repository]:Conflict EQUALS true)

ROLE_AOS-S_CONTACT-HD, API_SERVICE-NOW_PROFILE-CONFLICT

If a device's profiled category changes, ClearPass triggers the Conflict attribute.

Here we're saying if the Conflict attribute is true, put the device into a captive portal redirect to let them know to contact the help desk and also send an API call over to ServiceNow to open a ticket.

2 (Authorization:[Endpoints Repository]:Category NOT_EXISTS) ROLE_AOS-S_PROFILE

This rule evaluates whether the profile Category exists for the authenticating endpoint.

If it does not exist, the device has not been profiled and a captive portal redirect URL and **PROFILE** user role are returned to the switch.





NOTE: Captive portal redirect is not required for profiling. It's simply an example of leveraging features to improve user experience.

3



ROLE_AOS-S_GUEST, IETF_USERNAME_ENDPOINT

During role mapping, we were able to determine that the device should still be MAC Cached based on its expiration and the user's account status.

The GUEST user role and the guest's username/email will be returned.

4



ROLE_AOS-S_GUEST, IETF_USERNAME_ENDPOINT

This rule is similar to rule 3, but instead of checking for a Guest role, we're checking for the custom AD-User role which is configured for temporary guest access with valid AD credentials.

The GUEST user role and the user's AD username will be returned in the RADIUS response.

5

```
(Tips:Role MATCHES_ANY DEVICE_GAME-CONSOLE
DEVICE_MEDIA-PLAYER
DEVICE_PRINTER)
AND (Authorization:[Guest Device Repository]:Device Account Enabled
EQUALS true)
AND (Authorization:[Guest Device Repository]:Device Account Expired
EQUALS false)

AND (Authorization:[Guest Device Repository]:Device Account Expired
EQUALS false)
```

Many headless devices have been registered via the Device Registration portal. Here we're validating whether the authenticating device was registered as a game console, media player or printer and that the device account is enabled and hasn't expired.

This is an example of using a downloadable user role. The sponsor's username is also returned.

class ipv4 DHCP match udp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255 eq 67 exit class ipv4 DNS match udp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255 eq 53 class ipv4 HTTPS-ANY match tcp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255 eq 443 class ipv4 WLC-ANY match ip 0.0.0.0 255.255.255.255 100.66.10.0 Radius: Hewlett-Packard-Enterprise HPE-CPPM-Role 255.255.255.0 policy user HEADLESS class ipv4 DHCP action permit class ipv4 DNS action permit class inv4 HTTPS-ANY action permit class ipv4 WLC-ANY action permit aaa authorization user-role name HEADLESS policy HEADLESS reauth-period 86400 vlan-name EDGE HEADLESS

(Authorization:[Endpoints Repository]:Category BELONGS_TO VoIP Phone, Video Conferencing)

ROLE_AOS-S_VOICE, IETF_USERNAME_DEVICE-NAME

Based on profiling data, we're authorizing devices categorized as VoIP Phone and Video Conferencing by sending back a **VOICE** user role along with the profiled device name as the username (as an example).



(Tips:Role EQUALS DEVICE_ACCESS-POINT)

ROLE_AOS-S_DUR_HEADLESS, IETF_USERNAME_DEVICE-NAME


The last rule checks for a TIPS role/tag of DEVICE_ACCESS-POINT from the role mapping and assigns the **HEADLESS** downloadable user role and returns the device name as the username like in rule 5.

Profiler

The Profiler function allows for an unknown device to be automatically disconnected from the network once profile data has been collected and evaluated. This prevents a device from being "stuck" in a limited access role. During the second authentication, the new profile data can be used in the policy decision. This is a very common feature for MAC Authentication services.

Since we may want to drop a newly profiled device into a new user role with a different VLAN, the port will need to be bounced to force the device to re-DHCP.

Use caution in voice environments where client devices are connected behind a voice device. Bouncing a port after profiling a new device connected behind the voice device could result in interruption of voice service.



NOTE: In ClearPass 6.6.X, this enforcement profile is called [HPE Bounce Host-Port]. It was renamed to [ArubaOS Switching - Bounce Switch Port] in the 6.7.0 release.

ClearPass: 802.1X

Service Configuration

Create a new service of type 802.1X Wired.

Under More Options, check the **Authorization** boxes. The default service rules will work with an ArubaOS-Switch.

If there is a need to restrict the service to a particular group of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS TO GROUP** rule to reference a NAD group as seen in rule 3 below.



Authentication

This service will be supporting both secure certificate-based authentication (EAP-TLS) and traditional, legacy username and password authentication (PEAPv0/EAP-MSCHAPv2).

The username and password-based authentication will be used for two purposes:

- 1) Allow a BYOD device to initially connect and kick off the Onboard process to allow a certificate to be issued
- 2) Allow for domain-joined assets to use their computer/machine account to authenticate to the network as well as support machine + user workflows

Based on the above requirements, remove all the default EAP methods from the Authentication Methods list on the Authentication tab except for [EAP PEAP] and [EAP TLS].

NOTE: The default **[EAP TLS]** method does not have OCSP authorization configured and is being used here solely as an example. OCSP is used to check real-time validity of a certificate and enabling it is highly recommended. Special care should be taken when authenticating certificates from different certificate authorities. This is outside the scope of this document.


For Authentication Sources, you'll add our Active Directory identity store and also the **[Local User Repository]**. Authentication sources will vary in your environment.

The Local User Repository will be used in the example for infrastructure accounts like having an access point or VoIP phone authenticate securely to the network using the 802.1X framework.



Authorization


Since device profile information will be leveraged in policy, add the **[Endpoints Repository]** to the "Additional authorization sources..." list as shown below.



Roles

Role mapping is used to tag devices and users with as much prevalent information as possible for use in a policy decision.


These rules and tags will vary greatly by environment, but below you'll find examples of device and user tagging.



- Rules 1 and 4 are checking group membership from Active Directory
- Rules 2-3 are matching on the common name of the issuing CA for the authenticating certificate

Enforcement

Let's take apart this enforcement policy rule by rule:



(Tips:Role EQUALS [User Authenticated])

AND (Tips:Role EQUALS [Machine Authenticated])

ROLE_AOS-S_CORP

When a Windows device authenticates to the network using its Active Directory computer account, the [Machine Authenticated] tag/TIPS role is added to the session automatically.

If both a machine and user authentication have occurred, then return the CORP user role.

This is commonly used to validate that the user is using a corporate asset.

(Tips:Role EQUALS [Machine Authenticated]) ROLE_AOS-S_CORP

This checks for a Machine-only authentication. These typically occur when the device is sitting at the Windows logon screen and connectivity is required for updates, remote access or for new users to log in.

Wired Policy Enforcement Solution Guide

3

(Tips:Role EQUALS [User Authenticated])

AND (Endpoint:MDM Enabled EQUALS true)

AND (Endpoint:Compromised EQUALS false)

AND (Tips:Role EQUALS CERT_CORP-DEVICE-CA)

This is a typical rule to deal with a non-Windows corporate-managed asset that is managed by an EMM solution.

The two endpoint attributes have been synced down from the EMM solution via ClearPass Exchange. In this case, the rule is evaluating whether the device has its device management enabled and that no compromise has occurred.

The last condition checks for the tag/TIPS role from our role mapping to verify the certificate used to authenticate was issued from the Corporate Device CA.

4

(Authentication:OuterMethod EQUALS EAP-PEAP)

AND (Tips:Role EQUALS USER_ONBOARD-REQ)

ROLE_AOS-S_ONBOARD-ENROLL

Most personal devices will perform Onboarding through the captive portal workflow after 802.1X fails, but some users may authenticate via PEAPv0/EAP-MSCHAPv2 when prompted by their device.

This rule will catch those users who need to be using EAP-TLS authentication via ClearPass Onboard.

The user role **ONBOARD-ENROLL** and the Onboard enrollment URL are being returned to the switch.

Туре	Name		Value
1. Radius: Hewlett-Packard-Enterprise	HPE-User-Role	=	ONBOARD-ENROLL
2. Radius: Hewlett-Packard-Enterprise	HPE-Captive-Portal-URL	=	https://clearpass- demo.arubaboston.com/onboard/wired_onboard_1.php

5

(Tips:Role EQUALS USER_LIMITED-ACCESS)

ROLE_AOS-S_AD-TEMP

This is a basic rule as an example of a security exception for a group of users. These devices are dropped into the **AD-TEMP** role.

6

(Tips:Role EQUALS [User Authenticated])

AND (Tips:Role EQUALS CERT_ONBOARD-BYOD-CA)

ROLE_AOS-S_BYOD

After a device has been onboarded, subsequent authentications will occur via EAP-TLS. Rule 6 uses the tag from the role mapping to check the common name of the issuing CA. These devices will be dropped into a **BYOD** role.

7 (Authorization:[Endpoints Repository]:Category *EQUALS* Printer)
AND (Authorization:[Endpoints Repository]:Conflict *EQUALS* false)

ROLE_AOS-S_DUR_HEADLESS

Here the device category of Printer is being evaluated along with a check of the **Conflict** flag. Username/password vs certificate authentication in this case is irrelevant, however, an additional condition could easily be added similar to rules 8 and 9 below.

This example uses the **HEADLESS** downloadable user role.

```
class ipv4 DHCP
                                                                               match udp 0.0.0.0 255.255.255.255 0.0.0.0
                                                                               255.255.255.255 eq 67
                                                                               exit
                                                                               match udp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255 eq 53
                                                                               class ipv4 HTTPS-ANY
                                                                               match tcp 0.0.0.0 255.255.255.255 0.0.0.0
                                                                               255.255.255.255 eq 443
                                                                               exit
                                                                               class ipv4 WLC-ANY
                                                                               match ip 0.0.0.0 255.255.255.255 100.66.10.0
Radius: Hewlett-Packard-Enterprise HPE-CPPM-Role
                                                                               255.255.255.0
                                                                               policy user HEADLESS
                                                                               class ipv4 DHCP action permit
                                                                               class ipv4 DNS action permit
                                                                               class ipv4 HTTPS-ANY action permit
                                                                               class ipv4 WLC-ANY action permit
                                                                               aaa authorization user-role name HEADLESS
                                                                               policy HEADLESS
                                                                               reauth-period 86400
                                                                               vlan-name EDGE_HEADLESS
```

(Authorization:[Endpoints Repository]:Category BELONGS_TO
VoIP Phone, Video Conferencing)

AND (Authorization:[Endpoints Repository]:Conflict EQUALS false)

AND (Certificate:Subject-DN EQUALS CN=Wired Phones,OU=PKI Authority,O=Alcatel-Lucent,C=FR)

AND (Certificate:Issuer-DN EQUALS Alcatel Enterprise Solutions,OU=PKI Authority,O=Alcatel,C=FR)

Many voice devices come from the factory with an embedded certificate that can be used for network authentication. The phone's factory cert is being leveraged for EAP-TLS combined with profiling data. The **VOICE** user role is being passed back for these devices.

```
(Tips:Role EQUALS DEVICE_ACCESS-POINT)

AND (Authorization:[Endpoints Repository]:Category EQUALS Access
Points)

AND (Authorization:[Endpoints Repository]:Conflict EQUALS false)

AND (Authorization:Source EQUALS [Local User Repository])
```

As discussed during the authentication section, a local user account was created in ClearPass for use by access points to authenticate. Rule 9 is comparing the tag/TIPS role, category, conflict status and verifying the authentication source was the **[Local User Repository]**. The **HEADLESS** downloadable user role is being used like in rule 7.

9

ClearPass: Web Authentication

The Web Authentication service handles captive portal-based authentications with server-initiated workflows.


Service Configuration

Create a new service of type Web-based Authentication.

Check the Authorization box and select Matches ALL under Service Rule.

Add a second service rule with Application:ClearPass | Page-Name | EQUALS and then the page name.

For example: if the full page URL is https://<fqdn>/guest/wired_aruba_self-reg.php, then the page name is: wired_aruba_self-reg.



NOTE: The Page-Name attribute was added in ClearPass 6.7.0. Skip if using ClearPass 6.6.X.

Authentication


This service will be supporting both guest and Active Directory users for captive portal login.

For Authentication Sources, you'll add the [Guest User Repository] and also our Active Directory identity store. Authentication sources will vary in your environment.



Authorization


We will need to assign a manual expiration time to AD users. This time is calculated by the [Time Source] so it will need to be added as an additional authorization source.



Roles

In this scenario, guests and contractors will go through a standard self-registration process and any employee who authenticates with their corporate credentials will get a temporary guest role. Since there is no specific mapping of AD group, you'll use the generic [Guest Roles] role map.

If different enforcement actions will be taken for different groups or classifications of users, create a new role map like the in 802.1X configuration.



Enforcement

Because the server-initiated workflow is used with ArubaOS-Switch, the enforcement policy for the WEBAUTH service is very simple. The goal is to update the device endpoint record with attributes from the user authentication that will be stored and used for subsequent authentications and then bounce the port to trigger a reauthentication event.

Note: If a VLAN change is not required, a Terminate Session disconnect message can be used instead of a port bounce.

In this example, both guest and Active Directory accounts are being used.


For the guest accounts, a basic enforcement profile for MAC caching the user needs to be set up so when they re-authenticate after the port bounce, the user will not be prompted to authenticate again until their account expires.

Before creating the enforcement policy, create a new enforcement profile for the guest users (Configuration » Enforcement » Profiles » Add Enforcement Profile).

- 1. Select ClearPass Entity Update Enforcement from the Template dropdown
- 2. Give the profile a name
- 3. On the attributes tab, add the 3 entries below and then save.

 Note that the value field will require manual entry (copy and paste the values below).


TYPE	NAME	VALUE
Endpoint	Username	%{Authentication:Username}
Endpoint	Guest Role ID	%{GuestUser:Role ID}
Endpoint MAC-Auth Expiry %{Authorization:[Guest U		%{Authorization:[Guest User Repository]:ExpireTime}




Wired Policy Enforcement Solution Guide

Next, create an enforcement profile for the AD users following a similar process. Since captive portal-based access should only be temporary for employees, a manual expiration of one day will be used via [Time Source], a pre-built authentication source

TYPE	NAME	VALUE	
Endpoint	Username	%{Authentication:Username}	
Endpoint	Guest Role ID	AD-User	
Endpoint	MAC-Auth Expiry	%{Authorization:[Time Source]:One Day DT}	



Now, create a very basic enforcement policy. The first rule checks for a TIPS role / tag of [Guest]. The second rule checks that the Authentication Source is Active Directory. Both rules issue a CoA bounce switch port and then perform the appropriate endpoint update.



NOTE: In ClearPass 6.6.X, the enforcement profile [HPE Bounce Host-Port] is used.

Wired Policy Enforcement Solution Guide

ClearPass: Guest

Configuring a self-registration workflow in Guest is outside the scope of the document. For the purposes of this guide, the only relevant settings on the guest side are the **NAS Vendor Settings** and the **Login Delay**.



Under NAS Vendor Settings, be sure the Vendor Settings are set to Hewlett Packard Enterprise. This will tell Guest to use a server-initiated login and which will craft a WEBAUTH request which is handled by the service we previously created.



Under **Login Delay**, set the value to a minimum of 30 seconds. This is required with server-initiated workflows because you don't want the user to attempt to browse while the port is still down or their device is re-authenticating. You may need to adjust this value in your environment.



Useful Switch Troubleshooting Commands and Tips

show port-access config

This is a very useful command that shows you the AAA functions enabled globally and on each port.

```
Port Access Status Summary
  Port-access authenticator activated [No] : Yes
  Allow RADIUS-assigned dynamic (GVRP) VLANs [No] : No
  Dot1x2010 Mode [Disabled] : Disabled
                                                           Use LLDP data to authenticate [No] : No
         802.1X
                 802.1X
                           Web
                                     Mac
                                               LMA
                                                     Cntrl Mixed
                                                                      Speed
                                                                      VSA
                                                                            MBV
  Port
        Supp
                 Auth
                           Auth
                                     Auth
                                               Auth
                                                     Dir
                                                            Mode
                 Yes
                           No
                                     Yes
                                                     both
                                                                             Yes
  1
        No
                                               No
                                                            No
                                                                      No
  2
                           No
                                     Yes
        No
                 Yes
                                               No
                                                      both
                                                            No
                                                                      No
                                                                             Yes
  3
        No
                 Yes
                           No
                                     Yes
                                               No
                                                     both
                                                            No
                                                                      No
                                                                             Yes
  4
        No
                 Yes
                           No
                                     Yes
                                               No
                                                     both
                                                            No
                                                                      No
                                                                             Yes
  5
                 Yes
                           No
                                                     both
                                                                             Yes
        No
                                     Yes
                                               No
                                                            No
                                                                      No
  6
        No
                 Yes
                           No
                                     Yes
                                               No
                                                     both
                                                            No
                                                                      No
                                                                             Yes
        No
                 Yes
                           No
                                     Yes
                                               No
                                                     both
                                                            No
                                                                      No
                                                                             Yes
  8
                                               No
        No
                 Yes
                           No
                                     Yes
                                                     both
                                                            No
                                                                      No
                                                                             Yes
  9
        No
                 Yes
                           No
                                     Yes
                                               No
                                                     both
                                                            No
                                                                      No
                                                                             Yes
  10
                 Yes
                           No
                                               No
                                                                      No
                                                                             Yes
        No
                                     Yes
                                                     both
                                                            No
  11
                           No
                                     Yes
                                               No
                                                     both
        No
                 Yes
                                                            No
                                                                      No
                                                                             Yes
  12
        No
                 Yes
                           No
                                     Yes
                                               No
                                                      both
                                                            No
                                                                      No
                                                                             Yes
  13
        No
                 No
                           No
                                     No
                                               No
                                                     both
                                                                             Yes
                                                            No
                                                                      No
        No
                 No
                           No
                                     No
                                               No
                                                     both
                                                            No
                                                                      No
                                                                             Yes
```

show user-role

```
EDGE-2920# show user-role
 User Roles
  Enabled
                : Yes
  Initial Role
               : denyall
  Type
             Name
  local
             BYOD
  local
             CORP
             GUEST
  local
  local
             VOICE
  local
             SPLASH
  local
             AD-TEMP
  local
             PROFILE
  predefined denyall
             HEADLESS
  local
  local
             CONTACT-HD
             ONBOARD-ENROLL
  downloaded *ROLE_AOS_S_DUR_HEADLESS-3180-5
  downloaded *ROLE_AOS_S_DUR_T__AUTHENTICATED-3164-4
```

show user-role <role-name> detailed

```
EDGE-2920# show user-role SPLASH detailed
 User Role Information
   Name
                                        : SPLASH
                                        : local
   Type
   Reauthentication Period (seconds) : 0
   Untagged VLAN
                                        : EDGE_GUEST
   Captive Portal Profile
                                        : use-radius-vsa
                                        : (use RADIUS VSA)
     URL
   Policy
                                        : CLEARPASS-REDIRECT
Statements for policy "CLEARPASS-REDIRECT"
policy user "CLEARPASS-REDIRECT"
     10 class ipv4 "DNS" action permit
     20 class ipv4 "DHCP" action permit
     30 class ipv4 "CLEARPASS-WEB" action permit
40 class ipv4 "WEB-TRAFFIC" action redirect captive-portal
   exit
Statements for class IPv4 "DNS"
class ipv4 "DNS"
     10 match udp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255 eq 53
   exit
Statements for class IPv4 "DHCP" class ipv4 "DHCP"
     10 match udp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255 eq 67
   exit
Statements for class IPv4 "CLEARPASS-WEB" class ipv4 "CLEARPASS-WEB"
     10 match tcp 0.0.0.0 255.255.255.255 100.65.30.42 0.0.0.0 eq 80
     20 match tcp 0.0.0.0 255.255.255.255 100.65.30.42 0.0.0.0 eq 443
   exit
Statements for class IPv4 "WEB-TRAFFIC"
class ipv4 "WEB-TRAFFIC"
     10 match tcp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255 eq 80
     20 match tcp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255 eq 443
   exit
```

show port-access clients

Similar to show user-table on ArubaOS

```
EDGE-2920# show port-access clients
Port Access Client Status
 Port Client Name
                     MAC Address IP Address
                                                                     Type VLAN
                                                   User Role
       darth.vade... 00e04c-363b99 n/a
 2
                                                   HEADLESS
                                                                     MAC
                                                                           815
       host/win10... 90e2ba-692d5a n/a
                                                   CORP
                                                                     8021X 811
       HP IP Phone 2c4138-7fc880 100.81.3.10
                                                   VOICE
                                                                     MAC
                                                                           813
       Aruba AP
                     d8c7c8-cb497a n/a
                                                   HEADLESS
                                                                     MAC
                                                                           815
```

If ClearPass returned a user role, but the device is in a **denyall** role, there is likely a configuration issue with the user role. Run **show log -r** to display the system logs which should indicate an issue.

```
W 04/19/17 13:30:10 05208 dca: Failed to apply user role SPLASH to macAuth
client 90E2BA692D5A on port 3: required CAPTIVE-PORTAL-URL VSA was
not sent.
```

In this case, the role was configured to look for the captive portal redirect URL in the RADIUS response (use-radius-vsa) but the VSA was not present.

show port-access clients detailed <port>

```
EDGE-2920# show port-access clients detailed 3
 Port Access Client Status Detail
  Client Base Details :
   Port
                                           Authentication Type: 802.1x
   Client Status
                                           Session Time
                   : authenticated
                                                               : 265 seconds
                                           Session Timeout
                                                               : 86400 seconds
   Client name
                   : TIMCAPPALLI\tim
   MAC Address
                   : 90e2ba-692d5a
                   : 100.81.1.11
User Role Information
                                     : CORP
                                       local
   Reauthentication Period (seconds): 86400
   Untagged VLAN
                                     : 811
   Tagged
VLANs
   Captive Portal Profile
   Policy
                                     : PERMIT-ALL
Statements for policy "PERMIT-ALL"
policy user "PERMIT-ALL"
     10 class ipv4 "IP-ANY-ANY" action permit
   exit
Statements for class IPv4 "IP-ANY-ANY"
class ipv4 "IP-ANY-ANY"
    10 match ip 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255
   exit
```

show user-role downloaded

show user-role downloaded detailed
show user-role <NAME> downloaded detailed

```
EDGE-2930# show user-role downloaded detailed
Downloaded user roles are preceded by *
 User Role Information
                                       : *ROLE_AOS_S_DUR_PROFILE-3160-2
                                        : downloaded
   Reauthentication Period (seconds) : 60
   Untagged VLAN
                                        : UNTRUST
   Tagged VLAN
   Captive Portal Profile
   Policy
                                       : PROFILE_ROLE_AOS_S_DUR_PROFILE-3160-2
Statements for policy "PROFILE_ROLE_AOS_S_DUR_PROFILE-3160-2" policy user "PROFILE_ROLE_AOS_S_DUR_PROFILE-3160-2"
     10 class ipv4 "DHCP_ROLE_AOS_S_DUR_PROFILE-3160-2" action permit
   exit
Statements for class IPv4 "DHCP_ROLE_AOS_S_DUR_PROFILE-3160-2"
class ipv4 "DHCP_ROLE_AOS_S_DUR_PROFILE-3160-2"
     10 match udp 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255 eq 67
   exit
   Tunnelednode Server Redirect
                                       : Disabled
   Secondary Role Name
 User Role Information
                                       : *ROLE_AOS_S_DUR_HEADLESS-3180-5
   Name
   Type
                                       : downloaded
   Reauthentication Period (seconds): 86400
   Untagged VLAN
                                         SECURE-A
   Tagged VLAN
   Captive Portal Profile
   Policy
                                       : HEADLESS_ROLE_AOS_S_DUR_HEADLESS-3180-5
```

SNMP-based Enforcement

Policy Enforcement

VLAN assignment via SNMP is the primary enforcement method with OnConnect. VLAN access control lists (ACLs) are commonly used to control traffic in this scenario.

Configuration Overview

Here are the hardware and software combinations used for this configuration:

- Aruba 2920 switch running ArubaOS-Switch 16.03.0003 (no version dependency, but 16.01 or greater is recommended)
- ClearPass Policy Manager 6.6.4 (required: 6.6.1+)

This configuration example uses SNMP v2c. SNMPv3 is also supported for OnConnect.

Quirks and Limitations

- Active user visibility is available for Windows domain-joined machines only
- OnConnect enforcement takes an average of 60 seconds with WMI enabled

Switch Configuration

Global switch configuration:

snmp-server community OnConnectRO operator	create SNMP ro community for ClearPass
snmp-server community OnConnectRW operator unrestricted	create SNMP rw community for ClearPass
snmp-server host 4.3.2.1 community ClearPassOnConnect trap-level all	set ClearPass as the snmp trap destination
snmp-server trap-source 1.2.3.4	set the SNMP trap source address
snmp-server enable traps mac-notify	enable MAC notify traps globally

Interface configuration:


snmp-server enable traps link-change 17-20	enable link state traps for OnConnect interfaces
interface 17-20 mac-notify traps learned interface 17-20 mac-notify traps removed	enable MAC notifications for OnConnect interfaces
Interface 17-20 untagged vlan 812	set default untrusted VLAN

ClearPass: Basics

Server Configuration


Enable OnConnect under Server Configuration (Administration » Server Manager » Server Configuration)

NOTE: This is only required in ClearPass 6.6.X



Configure the SNMP v2c Trap Community under Administration » Server Manager » Server Configuration, Service Parameters, ClearPass network services.

This should match the community string defined in this switch configuration element: snmp-server host 100.65.30.42 community ClearPassOnConnect trap-level all



After changing the trap community, the **System auxiliary services** service needs to be restarted.

Navigate to Administration » Server Manager » Server Configuration, Services Control and locate System auxiliary services.

Click Stop ... Once the service has stopped, click Start to restart the service.

Network Device


Enable SNMP Read and configure the community strings for the device:



Enable SNMP Write and configure the community strings for the device. Also, configure the Default VLAN (generally this will be the guest or untrusted VLAN):



Enable Policy Manager to perform OnConnect Enforcement:



Use the **Query Ports** button to test the SNMP configuration. The list will be populated with the switch ports if all is working correctly. Individual interfaces can also be enabled for OnConnect enforcement by selecting them in the list and clicking **Add to Port Names** (or by manually adding them to the Port Names list).

Windows Management Instrumentation (WMI) Overview


During a port status change, ClearPass can query domain-joined Windows devices for the current logged in user. This information can then be compared with user account information in Active Directory during authorization.

Requirements:

- Active Directory user account with WMI remote access privileges
- Windows firewall must allow inbound access to WMI from ClearPass

WMI Configuration: ClearPass

Inside ClearPass, map the WMI credentials to the edge subnets under **Configuration** » **Profile Settings** » **WMI Configuration**.




ClearPass: Enforcement Profiles

Enforcement profiles for OnConnect are very basic.

For each enforcement VLAN, create a new SNMP Based Enforcement profile. Navigate to **Configuration** » **Enforcement** » **Profiles** » **Add Enforcement Profile**. Select **SNMP Based Enforcement** from the template dropdown.

Add the **VLAN ID** and **Reset Connection** attributes. You can also optionally add the **Session Timeout** attribute to trigger a re-evaluation of policy after a certain amount of time.




ClearPass: OnConnect Service

Service Configuration

Start with a new service of type ClearPass OnConnect Enforcement.

Under More Options, check the **Authorization**. This will enable the Authorization tab. The default service rules will work with an ArubaOS-Switch.

If there is a need to restrict the service to a particular set of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS_TO_GROUP** service rule to reference a NAD group as seen in rule 2 below.



Authentication

Since OnConnect does not do any traditional user or device authentication, the only option available on the Authentication tab is the Strip Username Rules configuration.

If you are not planning to use WMI, nothing has to be configured on the Authentication tab.


If you are planning to use WMI to grab the currently logged in user, the Strip Username Rules will need to be configured. WMI returns the username in down-level logon format (REALM\username) so the REALM will need to be stripped off before an authorization check can be done against Active Directory.

Use the \:user rule to strip the REALM from the down-level logon username.



Authorization

On the Authorization tab, add the [Endpoints Repository] and [Guest Device Repository] to the "Additional authorization sources..." list as shown below. If WMI-based authorization will be used, also add your Active Directory authentication source to the list so user properties can be evaluated.



Roles

Role mapping is used to tag devices and users with as much information as possible for use in a policy decision.


This *example* role map covers both headless devices and user mapping based off AD group membership. Headless devices are mapped using a mix of device registrations and raw profile data.



Enforcement

For the default policy, the default guest VLAN profile is specified. This is used when a request falls through the policy with no match which would be a guest in this case.

Let's take apart the enforcement rules one by one:



1 (Tips:Role EQUALS USER_CONTRACTOR) SNMP_VLAN_812

If the logged in user is a member of the "Contractor" AD group, the USER_CONTRACTOR tag/TIPS Role is mapped. This device is then given the GUEST VLAN, 812 in this example.

2 (Authorization:AD_TIMCAPPALLI-COM_UPN:UserDN EXISTS) SNMP_VLAN_811

This rule just checks that the logged in user is a domain user. All domain users will have a **UserDN** attribute. These devices will be placed into the "SECURE" VLAN, 811 in this case.

(Authorization:[Endpoints Repository]:Category BELONGS_TO VoIP Phone,Video Conferencing)

SNMP_VLAN_813

Profile data is being leveraged in rule 3 to drop voice devices into VLAN 813, the voice VLAN.

Tips:Role MATCHES_ANY DEVICE_GAME-CONSOLE

DEVICE_MEDIA-PLAYER
DEVICE_PRINTER
DEVICE_ACCESS-POINT)

SNMP_VLAN_815

These tags/TIPS roles are mapped based on the role assigned during Device Registration. These registered devices will be dropped into the "HEADLESS" VLAN, 815 in this case.

Useful Troubleshooting Commands and Tips

ClearPass

If OnConnect requests are not appearing in Access Tracker, take a look in Event Viewer. Below are some common error messages.

• Traps are being sent by the switch, but the network device definition in ClearPass does not have the port listed for OnConnect enforcement.



• The SNMP trap community is mismatched



Switch

show snmp-server traps

This command will give you a summary of the switch's SNMP configuration.

```
Trap Receivers
  Link-Change Traps Enabled on Ports [All] : All
                                           Current Status
  Traps Category
  SNMP Authentication
                                          Extended
  Password change
                                          Enabled
  Login failures
                                          Enabled
  Port-Security
                                         : Enabled
  Authorization Server Contact
                                         : Enabled
  DHCP-Snooping
                                         : Enabled
  DHCPv6-Snooping Out of Resource
                                         : Enabled
 DHCPv6-Snooping Errant Replies
                                         : Enabled
 Dynamic ARP Protection
                                         : Enabled
  Dynamic IP Lockdown
                                          Enabled
  Dynamic IPv6 Lockdown Out of Resource : Enabled
  Dynamic IPv6 Lockdown Violations
                                         : Enabled
  Startup Config change
                                         : Disabled
  Running Config Change
                                         : Disabled
  MAC address table changes
                                         : Enabled
 DHCP-Server
                                         : Enabled
  NTP-Client
                                         : Disabled
 ND Snooping Out of Resources Traps
                                         : Enabled
  Address
                         Community
                                                 Events
                                                                         Timeout
                                                          Type
                                                                 Retry
  100.65.30.42
                         ClearPassOnConnect
                                                 All
                                                                 3
                                                                          15
                                                          trap
```

show vlan port <X> detail

debug snmp
debug destination session

Debug commands can be used for more advanced troubleshooting and to verify that the switch is sending traps to ClearPass. **debug snmp** enables all SNMP debugging and **debug destination session** will echo all of the debug text to the current session. To disable, use **no debug snmp**.

Per-Port Tunneled-Node (PPTN)

Policy Enforcement

Per-Port Tunneled-Node allows for the same enforcement options as a wireless client. This includes stateful session processing, deep packet inspection, URL filtering and bandwidth contracts.

Configuration Overview

The hardware and software requirements for Per-Port Tunneled-Node are:

- Aruba switch running ArubaOS-Switch 16.02 or greater:
 - o 5400R
 - o 3810M / 3800
 - o 2930F / 2930M
 - o 2920
 - * Please refer to switch documentation for scalability numbers
- Aruba hardware mobility controller for tunnel termination running either ArubaOS 6.5+ or 8.1+
- ClearPass Policy Manager (no version dependency, but 6.6.4+ is recommended)

Here are the hardware and software combinations used for this example configuration:

- Aruba 2920 switch running ArubaOS-Switch 16.03.0003
- Aruba 7005 mobility controller (both ArubaOS 6.5.2 and 8.1.0.1 are used in the example)
- ClearPass Policy Manager 6.6.4

Because Per-Port Tunneled-Node uses the same guest configuration (client-initiated) as a wireless client, that portion will not be covered in this section.

Quirks and Limitations

- PPTN has a limit of 32 MAC addresses per port
- Each switch stack requires a unique VLAN for transport

Wired Policy Enforcement Solution Guide

Switch Configuration

Configuring Per-Port Tunneled-Node (PPTN) on an ArubaOS-Switch is very easy and only requires a few extra configuration elements.

vlan 4013 name TN-TRANSPORT	define tunneled-node transport VLAN (see explanation below)
tunneled-node-server controller-ip 100.66.1.100	enable dynamic authorization (CoA)
papi-security key-value <key></key>	*optional, only required if PAPI security is enabled on controller
interface 13-16 tunneled-node-server	enable tunneled-node on the appropriate ports
interface 13-16 untagged vlan 4013	assign same ports to TN transport VLAN

The tunneled-node transport VLAN is essentially a locally significant VLAN that needs to be defined on both the switch and controller. This VLAN does not have an L3 interface and should not be tagged upstream in the network. It is solely used inside the GRE tunnel.

With tunneled-node, the client device's VLAN is assigned and enforced by the controller. In a tunneled-node only deployment, no client device access networks need to be configured at the edge switch layer.

Wired Policy Enforcement Solution Guide

Aruba Controller Overview

From the controller perspective, tunneled-node traffic can leverage the same, pre-existing user roles and policies from a wireless deployment. You can even leverage the same client access VLANs.

For example: if the guest/open SSID uses a specific guest VLAN on the controller, that same VLAN can be used for wired guests via tunneled-node.

Another note: tunneled-node AAA configuration uses the same as a wired access interface on the controller. If your environment is already configured for authentication of the controller's switch ports, the existing configuration will work for tunneled-node client devices. The only configuration required in that case would be the TN transport VLAN.

Licensing

Per-Port Tunneled-Node is licensed in the same way as an access point and consumes 1 license set per switch stack. For centralized policy enforcement and visibility with PPTN, only AP and PEF licenses are required. If web filtering is required, WebCC would also be needed.

If the controller itself has all 4 licenses installed (AP, PEF, WebCC and RFProtect), one of each license will be consumed per switch stack, just like an access point.

For more information on ArubaOS 6.5 licensing, please see the ArubaOS 6.5 User Guide.

Aruba Controller Configuration

This section will cover ArubaOS 6.5. The configuration for ArubaOS 8 is nearly identical, it just uses the new hierarchical configuration model. This section also assumes your controller has already been configured with the basics (VLANs, IPs, NTP, licenses etc) and also that ClearPass has been defined as a RADIUS server and been placed into a RADIUS server group.

NOTE: If the controller you're working with is already configured to support wireless policy and the goal is to build a consistent policy across wired and wireless access, there is no need to configure new roles. The example below assumes there are no existing role or policy configurations on the controller.

Roles and Policies


For this example, 7 roles will be created in the controller: PROFILE, GUEST-ACCESS, SPLASH, HEADLESS, SECURE, ONBOARD-ENROLL and QUARANTINE. Each of these roles will have an attached firewall policy.

First, create netdestination with entries for your ClearPass server(s):

Configuration > Advanced Services > Stateful Firewall > Destinations



netdestination CLEARPASS no description no invert name clearpass-demo.arubaboston.com position 1 host 100.65.30.42 position 2 Next create a new policy that denies access to internal networks: Configuration > Security > Access Control > Policies > Add



alias user network 192.168.0.0 255.255.0.0 any deny


Also, create a policy that permits both DNS and DHCP.

ip access-list session DNS-DHCP any any svc-dhcp permit user any svc-dns permit

Now a captive portal profile: Configuration > Security > Authentication > L3 Authentication > Captive Portal Authentication > Add

- Set the Redirect Pause to 0
- Uncheck Logout popup window
- Set the **Login page** URL to the ClearPass guest self-registration page.
- Uncheck Show Welcome Page
- Add your ClearPass netdestination to the White List

Apply the config and then set the **Server Group** to the ClearPass RADIUS server group.



Now click back on the profile name and click Save As and call the new profile QUARANTINE.

- Uncheck User Login
- Change the Login page URL to the quarantine page

Repeat one more time for the **ONBOARD-ENROLL** profile.

Wired Policy Enforcement Solution Guide


```
aaa authentication captive-portal SPLASH
server-group CLEARPASS-DEMO
redirect-pause 0
no logout-popup-window
login-page https://clearpass-demo.net.arubaboston.com/guest/wired_aruba_self-reg_pptn.php
no enable-welcome-page
white-list CLEARPASS
aaa authentication captive-portal QUARANTINE
server-group CLEARPASS-DEMO
no user-logon
redirect-pause 0
no logout-popup-window
login-page https://clearpass-demo.net.arubaboston.com/guest/wired_aruba_self-reg_pptn.php
no enable-welcome-page
white-list CLEARPASS
```

Now create the 6 user roles. Only the first two roles will have a screenshot example.

Configuration > Security > Access Control > User Roles > Add.


PROFILE

Firewall Policies: DNS-DHCP



SPLASH

- Firewall Policies: logon-control, captiveportal
- Captive Portal Profile: SPLASH



user-role SPLASH access-list session logon-control access-list session captiveportal captive-portal SPLASH

ONBOARD-ENROLL

- Firewall Policies: logon-control, captiveportal
- Captive Portal Profile: ONBOARD-ENROLL

user-role ONBOARD-ENROLL access-list session logon-control access-list session captiveportal captive-portal ONBOARD-ENROLL

QUARANTINE

- Firewall Policies: logon-control, captiveportal
- Captive Portal Profile: QUARANTINE

user-role QUARANTINE access-list session logon-control access-list session captiveportal captive-portal QUARANTINE

GUEST-ACCESS

• Firewall Policies: logon-control, DENY-INTERNAL, allowall

user-role GUEST-ACCESS access-list session logon-control access-list session DENY-INTERNAL access-list session allowall

SECURE

Firewall Policies: allowall

user-role SECURE access-list session allowall

HEADLESS


• Firewall Policies: allowall

user-role HEADLESS access-list session allowall


AAA Configuration

Create a new AAA profile under Configuration > Security > Authentication > AAA Profiles

Assign **SPLASH** as the initial role and **GUEST-ACCESS** as the default 802.1X and MAC Authentication roles as ClearPass will be sending back the role name after authentication.




Now assign the various authentication profiles and server groups. Default can be used for both MAC Authentication and 802. 1X Authentication. The server groups should be configured for ClearPass.



Wired Policy Enforcement Solution Guide


To enable wired authentication, navigate to **Configuration > Advanced Services > All Profiles > Wireless LAN > Wired Authentication**, click **AAA** and select the PPTN profile.



aaa authentication wired profile PPTN

ClearPass: Basics

Define your controller(s) as a network device(s) under **Configuration** » **Network** » **Devices**. At a minimum, configure **Name**, **IP** or **Subnet Address**, **RADIUS Shared Secret** and **Vendor Name**.



ClearPass: MAC Authentication

Overview

The MAC Authentication service will handle headless devices like printers, phones, access points and others as well as provide the redirect URL for unknown devices and users to allow for a captive portal authentication.


In this scenario, we're leveraging the Guest Device Repository and Device Registration portal to allow endusers and IT staff to register headless and non-802.1X capable devices. These devices can be assigned a role and account lifetime.

Service Configuration

Start with a new service of type MAC Authentication.

Under More Options, check the **Authorization** box. This will enable a new tab. Be sure to follow the screenshot below. Notice that **NAS-Port-Type** and **Service-Type** are different than a traditional wireless service with an Aruba controller. These values are used to isolate the request as a wired MAC authentication coming from the controller.

If there is a need to restrict the service to a particular set of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS_TO_GROUP** rule to reference a NAD group as seen in rule 5 below.



Authentication


On the authentication tab, remove [MAC Auth] under Authentication Methods and add [Allow All MAC Auth].

For Authentication Sources, you'll add [Guest Device Repository] [Local SQL DB] and move it above [Endpoints Repository] [Local SQL DB].



Authorization

On the Authorization tab, add the [Endpoints Repository], [Guest User Repository] and [Guest Device Repository] to the "Additional authorization sources..." list as shown below.



By default, authorization data is only fetched from the authentication source where the user/device was found. So, for example, let's say a guest user's device is re-authenticating to the network within their account expiration window, you'll find the MAC address in the [Endpoints Repository] with some data like guest role and expiration time but we also want to check with ClearPass Guest to make sure an administrator hasn't disabled the account.

Roles

Role mapping is used to tag devices and users with as much information as possible for use in a policy decision.


- Rule 1 and 2 are checking to see that a guest user account is still valid and returning the [MAC Caching] tag / TIPS role
- Rules 3-12 map user and device role IDs to tags / TIPS roles for use in policy
- Rules 13-15 map profiling data to a tag / TIPS role for use in policy



Enforcement

For the default policy, the captive portal "splash" role is specified. This is used when a request falls through the policy with no match.

Let's take apart the enforcement rules one by one:



(Authorization:[Endpoints Repository]:Conflict EQUALS true) ROLE_AOS-W_QUARANTINE, VLAN_ARUBA_GUEST

If a device's profiled category changes, ClearPass triggers the Conflict attribute.

In this rule, if the Conflict attribute is true, the device is being placed into a captive portal redirect to let them know to contact the help desk. Also, the **GUEST** named VLAN is being returned using the Aruba-Name-User-Vlan VSA.



(Tips:Role EQUALS [Guest]) ROLE_AOS-W_GUEST, VLAN_ARUBA_GUEST,

AND (Tips:Role EQUALS [MAC Caching]) IETF_USERNAME_ENDPOINT

During role mapping, it was determined that the device should still be MAC Cached based on its expiration and the user's account status.

The **GUEST** user role and name VLAN as well as the guest's username/email will be returned to the controller.

(Authorization:[Endpoints Repository]:Category *EQUALS* Access ROLE_AOS-W_HEADLESS, VLAN_ARUBA_SECURE

Using profile data, access points will be assigned the **HEADLESS** role in the **SECURE** VLAN.

(Tips:Role MATCHES_ANY DEVICE_GAME-CONSOLE
DEVICE_MEDIA-PLAYER
DEVICE_PRINTER)
AND (Authorization:[Guest Device Repository]:Device Account Enabled
EQUALS true)
AND (Authorization:[Guest Device Repository]:Device Account Expired
EQUALS false)

ROLE_AOS-W_HEADLESS, VLAN_ARUBA_SECURE,
IETF_USERNAME_DEVICE-SPONSOR

Many headless devices have been registered via the Device Registration portal. This rule evaluates whether the authenticating device was registered as a game console, media player or printer and that the device account is enabled and hasn't expired.

The **HEADLESS** user role, **SECURE** VLAN name and the sponsor/owner's username are being returned to the controller for these devices.

(Authorization:[Endpoints Repository]:Category BELONGS_TO VOIP ROLE_AOS-W_HEADLESS, VLAN_ARUBA_SECURE, Phone, Video Conferencing)

ROLE_AOS-W_HEADLESS, VLAN_ARUBA_SECURE, IETF_USERNAME_DEVICE-NAME

Based on profiling data, devices categorized as VoIP Phone and Video Conferencing are being authorized by sending back a **VOICE** user role along with the profiled device name as the username (as an example) and the **SECURE** VLAN name.



(Authentication: MacAuth MATCHES_ANY NotApplicable, KnownClient, ROLE_AOS-W_SPLASH, VLAN_ARUBA_GUEST UnknownClient)

The last rule is the catch all rule and drops the device/user into the captive portal splash page for registration and/or authentication before continuing.


ClearPass: 802.1X

Service Configuration

Create a new service of type 802.1X Wired.

Under More Options, check the **Authorization** boxes. Be sure to follow the screenshot below. Notice that **Service-Type** is different than a traditional wired service. This value is used to isolate the request as a wired 802.1X request coming from the Aruba controller.

If there is a need to restrict the service to a particular group of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS_TO_GROUP** rule to reference a NAD group as seen in rule 4 below.



Authentication

This service will be supporting both secure certificate-based authentication (EAP-TLS) and traditional, legacy username and password authentication (PEAPv0/EAP-MSCHAPv2).

The username and password-based authentication will be used for two purposes:

- 3) Allow a BYOD device to initially connect and kick off the Onboard process to allow a certificate to be issued
- 4) Allow for domain-joined assets to use their computer/machine account to authenticate to the network as well as support machine + user workflows

Based on the above requirements, remove all the default EAP methods from the Authentication Methods list on the Authentication tab except for [EAP PEAP] and [EAP TLS].

NOTE: The default [EAP TLS] method does not have OCSP authorization configured and is being used here solely as an example. OCSP is used to check real-time validity of a certificate and enabling it is highly recommended. Special care should be taken when authenticating certificates from different certificate authorities. This is outside the scope of this document.


For Authentication Sources, you'll add our Active Directory identity store and also the **[Local User Repository]**. Authentication sources will vary in your environment.

The Local User Repository will be used in the example for infrastructure accounts like having an access point or VoIP phone authenticate securely to the network using the 802.1X framework.



Authorization


Since device profile information will be leveraged in policy, add the [Endpoints Repository] to the "Additional authorization sources..." list as shown below.



Roles

Role mapping is used to tag devices and users with as much prevalent information as possible for use in a policy decision.


These rules and tags will vary greatly by environment, but below you'll find examples of device and user tagging.



- Rules 1 and 4 are checking group membership from Active Directory
- Rules 2-3 are matching on the common name of the issuing CA for the authenticating certificate

Enforcement

Let's take apart this enforcement policy rule by rule:



(Tips:Role EQUALS [User Authenticated])

AND (Tips:Role EQUALS [Machine Authenticated])

ROLE_AOS-W_SECURE, VLAN_ARUBA_SECURE

When a Windows device authenticates to the network using its Active Directory computer account, the [Machine Authenticated] tag/TIPS role is added to the session automatically.

If both a machine and user authentication have occurred, then return the SECURE user role and VLAN name.

This is commonly used to validate that the user is using a corporate asset.

(Tips:Role EQUALS [Machine Authenticated]) ROLE_AOS-W_SECURE, VLAN_ARUBA_SECURE

Rule 2 is for a machine-only authentication. These typically occur when the device is sitting at the Windows logon screen and connectivity is required for updates, remote access or for new users to login.

3

```
(Tips:Role EQUALS [User Authenticated])

AND (Endpoint:MDM Enabled EQUALS true)

AND (Endpoint:Compromised EQUALS false)

AND (Tips:Role EQUALS CERT_CORP-DEVICE-CA)

ROLE_AOS-W_SECURE, VLAN_ARUBA_SECURE
```

This is a typical rule to deal with a non-Windows corporate-managed asset that is managed by an EMM solution.

The two endpoint attributes have been synced down from the EMM solution via ClearPass Exchange. In this case, the rule is evaluating whether the device has its device management enabled and that no compromise has occurred.

The last condition checks for the tag/TIPS role from our role mapping to verify the certificate used to authenticate was issued from the Corporate Device CA.

(Authentication:OuterMethod EQUALS EAP-PEAP)

AND (Tips:Role EQUALS USER_ONBOARD-REQ)

ROLE_AOS-W_ONBOARD-ENROLL, VLAN_ARUBA_SECURE

Most personal devices will perform Onboarding through the captive portal workflow after 802.1X fails, but some users may authenticate via PEAPv0/EAP-MSCHAPv2 when prompted by their device. This rule will catch those users who need to be using certificate-based authentication (EAP-TLS) via ClearPass Onboard.

The user role ONBOARD-ENROLL and SECURE VLAN name are returned to the controller.

(Tips:Role EQUALS [User Authenticated])

AND (Tips:Role EQUALS CERT_ONBOARD-BYOD-CA)

ROLE_AOS-W_SECURE, VLAN_ARUBA_SECURE

After a device has been onboarded, subsequent authentications will occur via EAP-TLS. Rule 6 uses the tag from the role mapping to check the common name of the issuing CA. These devices will be dropped into a **SECURE** role and VLAN.

(Authorization:[Endpoints Repository]:Category <u>EQUALS</u> Printer)

AND (Authorization:[Endpoints Repository]:Conflict <u>EQUALS</u> false)

ROLE_AOS-W_HEADLESS, VLAN_ARUBA_SECURE

This rule uses the device category of Printer combined with a check of the **Conflict** flag. The authentication method (username/password vs certificate) does not really matter in this case, however, an additional condition could easily be added similar to rules 7 and 8 below.

(Authorization:[Endpoints Repository]:Category BELONGS_TO
VoIP Phone, Video Conferencing)

AND (Authorization:[Endpoints Repository]:Conflict EQUALS false)

AND (Certificate:Subject-DN EQUALS CN=Wired Phones,OU=PKI
Authority,O=Alcatel-Lucent,C=FR)

AND (Certificate:Issuer-DN EQUALS Alcatel Enterprise
Solutions,OU=PKI Authority,O=Alcatel,C=FR)

Many voice devices come from the factory with an embedded certificate that can be used for network authentication. The factory cert is being leveraged for EAP-TLS combined with profiling data. The **HEADLESS** user role and **SECURE** VLAN name are being passed back for these devices.

8

```
(Tips:Role EQUALS DEVICE_ACCESS-POINT)

AND (Authorization:[Endpoints Repository]:Category EQUALS Access
Points)

AND (Authorization:[Endpoints Repository]:Conflict EQUALS false)

AND (Authorization:Source EQUALS [Local User Repository])
```

As discussed during the authentication section, a local user account was created in ClearPass for use by access points to authenticate. Rule 8 is comparing the tag/TIPS role, category, conflict status and verifying the authentication source was the <code>[Local User Repository]</code>

ClearPass: Web Authentication


The Web Authentication service handles captive portal-based authentications with server-initiated workflows.

Service Configuration

Create a new service of type RADIUS Based Enforcement (Generic).

Be sure to follow the screenshot below. Notice that **Service-Type** is set to **Login-User (1)** and **Aruba-Port-Id** just needs to be present in the request, regardless of value. These values are used isolate the request as a wired, RADIUS-based web authentication request coming from the Aruba controller.

If there is a need to restrict the service to a particular group of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS TO GROUP** rule to reference a NAD group as seen in rule 5 below.



Authentication


This service will be supporting both guest and Active Directory users for captive portal login.

For Authentication Sources, you'll add the [Guest User Repository] and also our Active Directory identity store. Authentication sources will vary in your environment.



Roles

In this scenario, guests will go through a standard self-registration process. Since no custom role mapping is being used, you'll select the generic [Guest Roles] role map.




Enforcement

Although the client device is wired, the web authentication will be processed just like a wireless client using a **controller-initiated** login, meaning that the client browser submits the credentials to the controller's web server and the controller in turn makes a RADIUS request to ClearPass.


Before creating the enforcement policy, create a new enforcement profile for the guest users (Configuration » Enforcement » Profiles » Add Enforcement Profile).

- 1. Select ClearPass Entity Update Enforcement from the Template dropdown
- 2. Give the profile a name
- 3. On the attributes tab, add the 3 entries below and then save. Note that the value field will require manual entry (copy and paste the values below).

TYPE	NAME	VALUE
Endpoint	Username	%{Authentication:Username}
Endpoint Guest Role ID %{GuestUser:Role ID}		%{GuestUser:Role ID}
Endpoint	MAC-Auth Expiry	%{Authorization:[Guest User Repository]:ExpireTime}



Now, create a very basic enforcement policy. The rule checks for a TIPS role / tag of [Guest] and returns the GUEST-ACCESS role in the RADIUS response and writes the username, role ID and expiration time to the endpoint database for use with MAC caching on subsequent authentications.



Useful Troubleshooting Commands and Tips

Controller

show tunneled-node config

```
Tunneled node Server:Enabled
Tunnel Loop Prevention:Disabled
```

show tunneled-node state

```
Tunneled Node State
------

IP MAC port state vlan tunnel inactive-time
-- --- --- --- ---- ---- -----

100.81.0.12 5c:b9:01:14:0a:00 13 complete 4013 9 0

100.81.0.12 5c:b9:01:14:0a:00 16 complete 4013 10 0

100.81.0.12 5c:b9:01:14:0a:00 15 complete 4013 11 0
```

show tunneled-node database

Switch

show tunneled-node-server state

```
Tunneled Node Port State

Active Controller IP Address : 100.66.1.100

Port State

13 Complete
14 Port down
15 Port down
16 Port down
```

Per-User Tunneled-Node (PUTN)

Policy Enforcement

Per-User Tunneled-Node (PUTN) allows for dynamic tunneling of user traffic to a mobility controller based on a policy decision. For example, devices like access points, printers and voice devices can stay locally switched, while a new unknown device, guest user or device with questionable posture can be tunneled to an Aruba mobility controller. Each device connected to a switch port is assigned a user role and in turn can stay local or be tunneled.

A new user role configuration element was added in ArubaOS-Switch 16.04 named **tunneled-node-server-redirect secondary-role**. The existing controller role that will be enforced for the tunneled client is defined as this secondary role. The switch will pass this secondary role name up to the controller where it will be enforced.

In this example, **T--QUARANTINE** is returned as the HPE-User-Role from ClearPass. This local user role has a secondary role defined which instructs the switch to tunnel this user to the active switch anchor controller in the defined VLAN. All of the client's traffic is then processed by the mobility controller.

The switch is in full control of authentication, authorization and accounting. ClearPass disconnect messages and change of authorization (CoA) requests are sent from ClearPass to the switch for enforcement.

With PUTN, the controller is a stateful, deep packet inspection and processing engine with enhanced visibility and control. All tunneled users appear in both the switch and controller user tables.

```
SWITCH
EDGE-2930# show port-access clients
Downloaded user roles are preceded by *
Port Access Client Status
 Port Client Name MAC Address
                                        IP Address
                                                         User Role
                                                                                 VLAN
                                                                           8021X 603
        darth.vade... 90e2ba-692d5a
                                        100.66.3.16
                                                         T--QUARANTINE
MOBILITY CONTROLLER
(some columns removed for readability)
(BOS-7010-1) *#show user-table role QUARANTINE
Users
    ΙP
                  MAC
                                 Name
                                          Role
                                                       Age(d:h:m)
                                                                   AP name
                                                                              Roaming
                                                                                       User Type
100.66.3.16 90:e2:ba:69:2d:5a
                                                                   tunnel 26
                                                                              Wired
                                                                                        TUNNELED USER
                                          quarantine
                                                       00:00:01
```

Configuration Overview

The hardware and software requirements for Per-User Tunneled-Node are:

- Compatible Aruba switch running ArubaOS-Switch 16.04 or greater:
 - o 5400R
 - o 3810M / 3800
 - o 2930F / 2930M
 - * Please refer to switch documentation for latest feature support and scalability numbers
- Aruba hardware mobility controller for tunnel termination running ArubaOS 8.1+
- ClearPass Policy Manager (no version dependency unless downloadable user roles are in use which requires 6.6.7+)

Here are the hardware and software combinations used for this example configuration:

- Aruba 2930F switch running ArubaOS-Switch 16.04.0008
- Aruba Virtual Mobility Master (VMM) running ArubaOS 8.1.0.1
- Aruba 7010 mobility controller running ArubaOS 8.1.0.1
- ClearPass Policy Manager 6.6.7

Quirks and Limitations

- Switch tunneled-node mode is global: per-user OR per-port
- PUTN has a limit of 32 MAC addresses per port
- Client VLANs defined on the controller must also be defined on the switch, but they should not be tagged through the network

Switch Configuration

This section will only cover configuration elements unique to Per-User Tunneled-Node (PUTN). The previous sections cover the full AAA configuration for 802.1X, MAC authentication, web authentication and user roles.

Define the controller VLANs where tunneled users will be assigned. These VLAN IDs must match the controller but the VLAN name can be different.

NOTE: These VLANs should only be created/defined. No IP address should be added and the VLAN should not be tied to any port.

vlan 602 name TN-SECURE	controller VLAN for trusted users
vlan 603 name TN-GUEST	controller VLAN for guest users
vlan 604 name TN-UNTRUST	controller VLAN for untrusted users

Define the switch anchor controller and globally enable role-based tunneled node (per-user).

tunneled-node-server	enter into TN global config
controller-ip 100.66.1.11	TN controller
mode role-based	globally enable role-based TN

Create local user roles with the secondary-role attribute.

NOTE: The secondary-role name is case-sensitive and ArubaOS 8.x stores everything as lowercase. The secondary-role definition on the switch must be lowercase.


aaa authorization user-role name TQUARANTINE	define the LUR
vlan-id 604	assign controller's client access VLAN
tunneled-node-server-redirect secondary-role quarantine	assign controller user role

ClearPass Configuration

Local User Roles (LURs)

When using a local user role (LUR) with PUTN, the ClearPass configuration remains the same as any other user role enforcement.

A user role name is simply returned to the switch using the HPE-User-Role VSA.




Downloadable User Roles (DURs)


From the role definition standpoint, downloadable user roles with PUTN use the same Aruba Downloadable Role Enforcement template and configuration with the addition of the tunneled-node-server-redirect secondary-role statement. See the Downloadable User Roles (DURs) section earlier in this document for more details and configuration requirements for DURs.

Below are two examples of DURs with PUTN.

NOTE: VLAN name can be used with PUTN for flexibility as long as the VLAN ID with this name on the switch is the same VLAN ID that will be used for client access on the controller.

For example, if VLAN 603 is the client access VLAN on the controller, the VLAN name defined on the switch must be for VLAN 603.





Role and Enforcement Profile Naming

Role and profile naming conventions can greatly assist with policy creation as well as reporting. The ability to quickly determine that a downloadable tunneled role was used instead of a local user role just from the name is invaluable.

For the PUTN examples used in this guide, all switch user roles with a secondary-role definition use the naming convention T--{CONTROLLER-ROLE-NAME}.

```
EDGE-2930# show user-role
Downloaded user roles are preceded by *
 User Roles
  Enabled
                     : Yes
  Initial Role : denyall
  Type
                 Name
  local
                 VOICE
                                        <<< user/traffic stays local
                                        <<< user/traffic stays local
  local
                 SECURE
  predefined denyall
                                        <<< user/traffic tunneled, controller role = SECURE</pre>
  local
                 T--SECURE
                                        <<< user/traffic tunneled, controller role = PROFILE
<<< user/traffic tunneled, controller role = HEADLESS
<<< user/traffic tunneled, controller role = QUARANTINE</pre>
  local
                 T--PROFILE
  local
                 T--HEADLESS
                 T--OUARANTINE
  local
                                        <<< user/traffic stays local</pre>
                 COMPUTER-SECURE
  local
```

Along the same lines for downloadable user roles, DUR enforcement profile examples in this guide use the naming convention ROLE_AOS-S_DUR_{ROLE-NAME}.

#	Name △	Туре	Description
1.	ROLE_AOS-S_DUR_HEADLESS	RADIUS	ArubaOS-Switch DUR
2.	ROLE_AOS-S_DUR_PROFILE	RADIUS	ArubaOS-Switch DUR
3.	ROLE_AOS-S_DUR_SPLASH	RADIUS	ArubaOS-Switch DUR
4.	ROLE_AOS-S_DUR_TCOMPUTER-SECURE	RADIUS	ArubaOS-Switch DUR with secondary user-role
5.	ROLE_AOS-S_DUR_TPROFILE	RADIUS	ArubaOS-Switch DUR with secondary user-role for centralized device profiling
6.	ROLE_AOS-S_GAME-CONSOLE	RADIUS	ArubaOS-Switch Local User Role
7.	ROLE_AOS-S_GUEST	RADIUS	ArubaOS-Switch Local User Role

Useful Troubleshooting Commands and Tips

show tunneled-node-server state

```
EDGE-2930# show tunneled-node-server state
Local Master Server (LMS) State
             IP Address
LMS Type
                              State
                                           Capability Role
Primary
          : 100.66.1.11
                              Complete
                                           Per User
                                                      Operational Primary
Switch Anchor Controller (SAC) State
              IP Address
                               Mac Address
                                                       State
SAC
            : 100.66.1.11
                               000b86-dd4a40
                                                       Registered
User Anchor Controller (UAC): 100.66.1.11
                             VLAN
                                                    Bucket ID
                  Port
                                        State
User
90e2ba-692d5a
                  5
                             603
                                        Registered
                                                    30
```

show tunneled-node-user all

```
EDGE-2930# show tunneled-node-user all

PORT MAC-ADDRESS TUNNEL-STATUS SECONDARY-USERROLE FAILURE-REASON
5 90e2ba-692d5a UP quarantine
```

HPE FlexNetwork (Comware v7) Enforcement

RADIUS-based Enforcement

Policy Enforcement

Access Control Lists (ACLs)

HPE Comware 7-based switches use locally defined ACLs that can be referenced via RADIUS.

ACLs are defined locally on the switch and can be returned as part of a RADIUS response or added directly to a switch port or VLAN interface.

VLAN Enforcement

VLANs in CW7 can be referenced by VLAN-ID or VLAN name. Although it is an optional configuration, VLAN name is highly recommended in a colorless port deployment as it removes the need for ClearPass to maintain a VLAN to function mapping for each switch. This simplifies policy creation, management and troubleshooting.

For example, each switch might use a different VLAN-ID for "secure access". Instead of having to write complex policy in ClearPass to return the correct VLAN-ID for each switch, we just give the appropriate VLAN-ID a name on each switch; "SECURE" for example. Now in your ClearPass policy, you simply return a VLAN enforcement with "SECURE" as the VLAN-ID and each switch will use the appropriate VLAN-ID mapped locally on the switch.

Dynamic Authorization

CW7 switches support the following dynamic authorization commands:

- Terminate Session: traditional disconnect message; reinitializes authenticator state
- Bounce Host Port: bounces the port by disabling and re-enabling the port
- Disable Host Port: administratively disables the port

NOTE: In ClearPass 6.6.X and earlier, the pre-defined Cisco dynamic authorization enforcement profiles need to be used with CW7 switches. In ClearPass 6.7.X+, use the pre-built H3C dynamic authorization enforcement profiles.

Configuration Overview

Here are the hardware and software combinations used for this configuration:

- HPE 5130 El switch running Comware 7.10.R3115P07
- ClearPass Policy Manager 6.6.4 (there are no ClearPass version dependencies for this configuration)

This configuration has been tested on the HPE 5130EI, 5130HI and 5510HI. The minimum versions of Comware 7 required for this configuration are:

- 5130_EI_7.10.R3113P02
- 5130_HI_7.10.R1308
- 5510_HI_7.10.R1308

Quirks and Limitations

• Comware 7 will not accept an ACL name via the RADIUS **filter-id** or **url-redirect** attributes. The ACL number must be sent. If you do not send an ACL in the RADIUS response and there is no ACL statically configured on the port, all traffic is permitted for that session.

Switch Configuration

The configuration snippets below assume that components like VLANs, uplinks, NTP and other basics have already been configured. Note that NTP is required as accurate time plays a critical role in network authentication.

CW7 uses the concept of authentication domains and schemes. You first create a scheme for the protocol (RADIUS in this case) and then map the authentication scheme to the domain. Then enable the newly created authentication domain as the global default.

```
radius scheme clearpass

primary authentication 100.65.30.42 key simple L0ng&Compl5x$ecret!

primary accounting 100.65.30.42 key simple L0ng&Compl5x$ecret!

accounting-on enable

user-name-format keep-original

#

domain clearpass

authentication lan-access radius-scheme clearpass

authorization lan-access radius-scheme clearpass

accounting lan-access radius-scheme clearpass

#

domain default enable clearpass

#
```

Set the NAS-IP to the RADIUS source address (usually the switch's management IP) and configure your ClearPass server(s) as a RADIUS dynamic authorization client(s) to support Change of Authorization.

```
radius nas-ip 100.81.0.11
#

radius dynamic-author server
  client ip 100.65.30.42 key simple L0ng&Compl5x$ecret!
#
```

Enable global functions and configurations:

port-security enable port-security mac-move permit	enable port authentication
dhcp snooping enable	provides IP visibility
dot1x authentication-method eap	enable EAP-based 802.1X
dot1x timer supp-timeout 10 dot1x timer tx-period 10	set 802.1X timers

Define access control entries:

```
acl number 3900 name ALLOWALL
rule permit ip
                                                                         allow all
acl number 3902 name PROFILE
                                                                         unknown
rule permit udp destination-port eq bootps
                                                                         endpoint
rule permit udp destination-port eq dns
                                                                         profiling
acl number 3910 name CLEARPASS-REDIRECT
description CLEARPASS-REDIRECT
                                                                         captive portal
rule permit tcp destination 100.65.30.42 0 destination-port eq 443
rule permit tcp destination 100.65.30.42 0 destination-port eq www
                                                                         redirect +
rule permit tcp destination 100.65.30.42 0 destination-port eq 6658
                                                                         OnGuard Agent
rule permit udp destination-port eq dns
                                                                         communication
rule permit udp destination-port eq bootps
acl number 3911 name INTERNET-ONLY
rule permit udp destination-port eq bootps
rule permit udp destination-port eq dns
                                                                         deny internal
rule deny ip destination 100.64.0.0 0.31.255.255
                                                                         access
rule permit ip
acl number 3912 name BYOD
                                                                         deny restricted
rule permit udp destination-port eq bootps
                                                                         networks for
rule permit udp destination-port eq dns
rule deny ip destination 100.65.0.0 0.0.255.255
                                                                         personal
rule permit ip
                                                                         devices
```


Configure end-user ports:

interface GigabitEthernet1/0/1	
port link-type hybrid	supports VoIP devices with clients behind them
port hybrid vlan 813 tagged port hybrid vlan 1 untagged	set voice VLAN as tagged set dead-end VLAN as untagged
undo voice-vlan mode auto	disable OUI based voice VLAN
voice-vlan 813 enable	voice VLAN
mac-vlan enable	MAC to VLAN mapping
undo dot1x handshake	not needed, see CW7 docs


dot1x mandatory-domain clearpass	use 'clearpass' domain for 1X
undo dot1x multicast-trigger	disable, can cause issues with VoIP phones
dot1x unicast-trigger	^ unicast EAP Request to unknown MAC
dot1x re-authenticate	allow periodic reauthentication
dot1x re-authenticate server-unreachable keep-online	keeps authenticated 802.1X users online when server not reachable for 802.1X reauthentication
mac-authentication max-user 10	max number of MA users connected to port
mac-authentication domain clearpass	use 'clearpass' domain for MA
mac-authentication timer auth-delay 15	wait 15 seconds before initiating MA
mac-authentication re-authenticate server-unreachable keep-online	keeps authenticated MA users online when server not reachable for MAC reauthentication
mac-authentication host-mode multi-vlan	allows multiple MAC-VLAN mappings per port
mac-authentication parallel-with-dot1x	initiate 802.1X and MA simultaneously
mac-authentication re-authenticate	allow periodic reauthentication
port-security port-mode userlogin-secure-or-mac-ext	allow authentication of multiple 802.1X and/or MA users
dhcp snooping binding record	add snooping entry to table

ClearPass: Basics

Comware 7 uses the H3C RADIUS dictionary and new RADIUS VSAs were added to support some new features like captive portal redirect. In ClearPass 6.7.X, Verify that the dictionary in your ClearPass instance has attribute #210, H3C-AVPair and attribute #250, H3C-Web-URL. If either of these are missing (ClearPass 6.6.X and earlier), download and import the latest dictionary file from support.arubanetworks.com. Instructions for importing a new or updated RADIUS dictionary can be found in the <u>ClearPass User Guide</u>.



Define your switch(es) as a network device(s) under **Configuration** » **Network** » **Devices**. At a minimum, configure **Name**, **IP** or **Subnet Address**, **RADIUS Shared Secret** and **Vendor Name**.



NOTE: If ClearPass 6.6.X or earlier is in use, define the vendor as Cisco.

Dynamic authorization templates for H3C (used with Comware) were added in ClearPass 6.7.0.

ClearPass: MAC Authentication

Overview

The MAC Authentication service will handle headless devices like printers, phones, access points and others as well as provide the redirect URL for unknown devices and users to allow for a captive portal authentication.

In this scenario, we're leveraging the Guest Device Repository and Device Registration Portal to allow endusers and IT staff to register headless and non-802.1X capable devices. These devices can be assigned a role and account lifetime.

Service Configuration

Start with a new service of type MAC Authentication.

Under More Options, check the **Authorization** and **Profile Endpoints** boxes. This will enable two new tabs. The default service rules will work with a CW7 switch.

If there is a need to restrict the service to a particular set of switches, you can use a Connection | NAD-IP-Address | BELONGS_TO_GROUP rule to reference a NAD group as seen in rule 4 below.



Authentication

On the authentication tab, remove **[MAC Auth]** under Authentication Methods and add **[Allow All MAC Auth]**.


For Authentication Sources, you'll add [Guest Device Repository] [Local SQL DB] and move it above [Endpoints Repository] [Local SQL DB].



Authorization

On the Authorization tab, add the **[Endpoints Repository]**, **[Guest User Repository]** and **[Guest Device Repository]** to the "Additional authorization sources…" list as shown below.

By default, authorization data is only fetched from the authentication source where the user/device was found.



So, for example, let's say a guest user's device is re-authenticating to the network within their account expiration window, you'll find the MAC address in the [Endpoints Repository] with some data like guest role and expiration time but we also want to check with ClearPass Guest to make sure an administrator hasn't disable the account.

Roles


Role mapping is used to tag devices and users with as much information as possible for use in a policy decision.

- Rule 1 and 2 are checking to see that a guest user account is still valid and returning the [MAC Caching] tag / TIPS role
- Rules 3-12 map user and device role IDs to tags / TIPS roles for use in policy
- Rules 13-15 map profiling data to a tag / TIPS role for use in policy



Enforcement

Let's take apart this enforcement policy rule by rule:



(Authorization:[Endpoints Repository]:Conflict EQUALS true) [Deny Access Profile], API_SERVICE-NOW_PROFILE-CONFLICT

If a device's profiled category changes, ClearPass triggers a Conflict attribute.

If the Conflict attribute is true, deny access to the network and also send an API call over to ServiceNow to open a ticket.


Other options could include a captive portal redirect to notify the user, text message to the user, etc.

2

(Authorization:[Endpoints Repository]:Category NOT_EXISTS) VLAN_EDGE--GUEST-300S, COMWARE_URLREDIRECT_PROFILING

This rule evaluates whether the profile Category exists for the authenticating endpoint.

If it does not exist, the device has not been profiled and a redirect URL, ACL number, short session-timeout and a VLAN assignment are returned to the switch.





NOTE: Captive portal is not required for profiling. It's simply an example of leveraging features to improve user experience.

3

(Tips:Role EQUALS [Guest])

AND (Tips:Role EQUALS [MAC Caching])

VLAN_EDGE--GUEST, FILTER-ID_3911--INTERNET-ONLY

During role mapping, we were able to determine that the device should still be MAC Cached based on its expiration and the user's account status.

The EDGE_GUEST VLAN and the ACL number for internet only access will be returned.

4

```
(Tips:Role MATCHES_ANY DEVICE_GAME-CONSOLE

DEVICE_MEDIA-PLAYER

DEVICE_PRINTER)

AND (Authorization:[Guest Device Repository]:Device Account Enabled

EQUALS true)

AND (Authorization:[Guest Device Repository]:Device Account Expired

EQUALS false)

VLAN_EDGE--HEADLESS, FILTER-ID_3900--ALLOWALL

EQUALS false)
```


Many headless devices have been registered via the Device Registration portal. Here we're validating whether the authenticating device was registered as a game console, media player or printer and that the device account is enabled and hasn't expired.

The EDGE_HEADLESS VLAN is being returned along with the ACL number for ALLOWALL.

5

```
(Authorization:[Endpoints Repository]:Category <u>BELONGS_TO</u> VoIP FILTER-ID_3900--ALLOWALL, H3C_DEVICE-TRAFFIC-CLASS_VOICE
```

Based on profiling data, devices categorized as VoIP Phone and Video Conferencing are authorized by sending back a filter-id and device-traffic-class.



This device-traffic-class=voice attribute/value pair tells the switch that this device should be treated as a voice device. Since the ports are configured as hybrid and a voice VLAN is mapped, the voice VLAN will be tagged down to the voice device.

```
<EDGE-5130EI>dis mac-authentication connection interface GigabitEthernet 1/0/3
Total connections: 1

Slot ID: 1
User MAC address: 2c41-387f-c880
Access interface: GigabitEthernet1/0/3
Username: 2c41387fc880
Authentication domain: clearpass
Initial VLAN: 813
Authorization untagged VLAN: N/A
Authorization tagged VLAN: 813
Authorization ACL ID: 3900
Authorization URL: N/A
Termination action: Default
Session timeout period: N/A
Online from: 2017/04/03 01:42:42
Online duration: 0h 5m 56s
```

6

(Authentication: MacAuth MATCHES_ANY NotApplicable, KnownClient, VLAN_EDGE--GUEST-300S, COMWARE_URL-REDIRECT_SELF-REG UnknownClient)

The last rule is effectively a "catch all" which handles unknown devices.

Enforcement action #1 uses the **url-redirect-acl** H3C-AVPair to tell the switch to use ACL number 3910 on the switch for redirection to the captive portal.

Action #2 provides the redirect URL to the switch using the **url-redirect** H3C-AVPair. Notice that we added a variable to dynamically appended the client MAC address to the URL. This is required for many guest workflows.




The second enforcement profile returns the **EDGE_GUEST** VLAN and a session-timeout which cause the device to be reauthenticated every 5 minutes until registered.

Profiler

The Profiler function allows for an unknown device to be automatically disconnected from the network once profile data has been collected and evaluated. This prevents a device from being "stuck" in a limited access role. During the second authentication, the new profile data can be used in the policy decision. This is a very common feature for MAC Authentication services.

Since we may want to drop a newly profile device into a new VLAN, the port will need to be bounced to force the device to re-DHCP.

Use caution in voice environments where client devices are connected behind a voice device. Bouncing a port after profiling a client device connected behind the voice device could result in interruption of voice service.



NOTE: In ClearPass 6.6.X and earlier, use the [Cisco - Bounce-Host-Port] enforcement profile.


ClearPass: 802.1X

Service Configuration

Create a new service of type 802.1X Wired.

Under More Options, check the **Authorization** boxes. The default service rules will work with an ArubaOS-Switch.

If there is a need to restrict the service to a particular group of switches, you can use a Connection | NAD-IP-Address | BELONGS_TO_GROUP rule to reference a NAD group as seen in rule 3 below.



Authentication

This service will be supporting both secure certificate-based authentication (EAP-TLS) and traditional, legacy username and password authentication (PEAPv0/EAP-MSCHAPv2).

The username and password-based authentication will be used for two purposes:

- 1) Allow a BYOD device to initially connect and kick off the Onboard process to allow a certificate to be issued
- 2) Allow for domain-joined assets to use their computer/machine account to authenticate to the network as well as support machine + user workflows

Based on the above requirements, remove all the default EAP methods from the Authentication Methods list on the Authentication tab except for [EAP PEAP] and [EAP TLS].

NOTE: The default **[EAP TLS]** method does not have OCSP authorization configured and is being used here solely as an example. OCSP is used to check real-time validity of a certificate and enabling it is highly recommended. Special care should be taken when authenticating certificates from different certificate authorities. This is outside the scope of this document.


For Authentication Sources, you'll add our Active Directory identity store and also the **[Local User Repository]**. Authentication sources will vary in your environment.

The Local User Repository will be used in the example for infrastructure accounts like having an access point or VoIP phone authenticate securely to the network using the 802.1X framework.



Authorization

Since device profile information will be leveraged in policy, add the **[Endpoints Repository]** to the "Additional authorization sources..." list as shown below.



Roles

Role mapping is used to tag devices and users with as much prevalent information as possible for use in a policy decision.


These rules and tags will vary greatly by environment, but below you'll find examples of device and user tagging.



- Rules 1 and 4 are checking group membership from Active Directory
- Rules 2-3 are matching on the common name of the issuing CA for the authenticating certificate

Enforcement

Let's take apart this enforcement policy rule by rule:



(Tips:Role EQUALS [User Authenticated]) VLAN_EDGE--SECURE, FILTER-ID_3900--ALLOWALL (Tips:Role EQUALS [Machine Authenticated])

When a Windows device authenticates to the network using its Active Directory computer account, the [Machine Authenticated] tag/TIPS role is added to the session automatically.

If both a machine and user authentication have occurred, then return the **EDGE_SECURE** VLAN name and filter-ID **3900** which matches an allowall ACL locally on the switch.

This is commonly used to validate that the user is using a corporate asset.

(Tips:Role EQUALS [Machine Authenticated]) VLAN_EDGE--SECURE, FILTER-ID_3900--ALLOWALL

Rule 2 is for a machine-only authentication. These typically occur when the device is sitting at the Windows logon screen and connectivity is required for updates, remote access or for new users to login.

3



This is a typical rule to deal with a non-Windows corporate-managed asset that is managed by an EMM solution. The two endpoint attributes have been synced down from the EMM solution via ClearPass Exchange. In this case, the rule is evaluating whether the device has its device management enabled and that no compromise has occurred. The last condition checks for the tag/TIPS role from our role mapping to verify the certificate used to authenticate was issued from the Corporate Device CA.

4



Most personal devices will perform Onboarding through the captive portal workflow after 802.1X fails, but some users may authenticate via PEAPv0/EAP-MSCHAPv2 when prompted by their device. This rule will catch those users who need to be using certificate-based authentication (EAP-TLS) via ClearPass Onboard.

A **url-redirect-acl** number is returned to the switch along with the Onboard enrollment URL via the H3C-AVPair attributes. This ACL was configured locally on the switch earlier.

Туре	Name	Value
1. Radius: H3C	H3C-AVPair	= url-redirect-acl=3910
2. Radius:H3C	H3C-AVPair	url-redirect=https://clearpass- = demo.net.arubaboston.com/onboard/wired_onboard_1.php? mac=%{Connection:Client-Mac-Address-Colon}

5

```
(Tips:Role EQUALS [User Authenticated])

AND (Certificate:Issuer-CN EQUALS ClearPass Demo Onboard Signing VLAN_EDGE--SECURE, FILTER-ID_3912--BYOD Intermediate CA)
```

After a device has been onboarded, subsequent authentications will occur via EAP-TLS. Rule 5 uses the tag from the role mapping to check the common name of the issuing CA. These devices will be dropped into the **EDGE_SECURE** VLAN with 3912 returned as a filter-ID which is the BYOD ACL locally defined on the switch.

6

```
(Authorization:[Endpoints Repository]:Category BELONGS_TO
VoIP Phone, Video Conferencing)

AND (Authorization:[Endpoints Repository]:Conflict EQUALS false)

AND (Certificate:Subject-DN EQUALS CN=Wired Phones,OU=PKI
Authority,O=Alcatel-Lucent,C=FR)

AND (Certificate:Issuer-DN EQUALS Alcatel Enterprise
Solutions,OU=PKI Authority,O=Alcatel,C=FR)
```

Many voice devices come from the factory with an embedded certificate that can be used for network authentication. Here we're leveraging the factory cert for EAP-TLS combined with profiling data.

This **device-traffic-class=voice** attribute/value pair tells the switch that this device should be treated as a voice device. Since the ports are configured as hybrid and a voice VLAN is mapped, the voice VLAN will be tagged down to the voice device. The ACL number for allowall is also passed as a filter-id.

ClearPass: Web Authentication

The Web Authentication service handles captive portal-based authentications with server-initiated workflows.


Service Configuration

Create a new service of type Web-based Authentication.

Check the Authorization box and select Matches ALL under Service Rule.

Add a second service rule with Application:ClearPass | Page-Name | EQUALS and then the page name.

For example: if the full page URL is https://<fqdn>/guest/wired_cw7_self-reg.php, then the page name is: wired_cw7_self-reg.



NOTE: The Page-Name attribute was added in ClearPass 6.7.0. Skip if using ClearPass 6.6.X.

Authentication


This service will be supporting both guest and Active Directory users for captive portal login.

For Authentication Sources, you'll add the [Guest User Repository] and also our Active Directory identity store. Authentication sources will vary in your environment.



Authorization


We will need to assign a manual expiration time to AD users. This time is calculated by the [Time Source] so it will need to be added as an additional authorization source.



Roles

In this scenario, guests and contractors will go through a standard self-registration process and any employee who authenticates with their corporate credentials will get a temporary guest role. Since there is no specific mapping of AD group, you'll use the generic [Guest Roles] role map.

If different enforcement actions will be taken for different groups or classifications of users, create a new role map like the in 802.1X configuration.



Enforcement

Because the server-initiated workflow is used with Comware 7, the enforcement policy for the WEBAUTH service is very simple. The goal is to update the device endpoint record with attributes from the user authentication that will be stored and used for subsequent authentications and then bounce the port to trigger a reauthentication event.

Note: If a VLAN change is not required, a Terminate Session disconnect message can be used instead of a port bounce.

In this example, only guest users are permitted.


A basic enforcement profile for MAC caching the device is used so when re-authenticating after the port bounce, the user will not be prompted to authenticate again until their account expires.

Before creating the enforcement policy, create a new enforcement profile for the guest users (Configuration » Enforcement » Profiles » Add Enforcement Profile).

- Select ClearPass Entity Update Enforcement from the Template dropdown
- Give the profile a name
- On the attributes tab, add the 3 entries below and then save


Note that the value field will require manual entry (copy and paste the values below)

TYPE	NAME	VALUE
Endpoint	Username	%{Authentication:Username}
Endpoint	Guest Role ID	%{GuestUser:Role ID}
Endpoint	MAC-Auth Expiry	%{Authorization:[Guest User Repository]:ExpireTime}



Now, create a very basic enforcement policy with a single rule which checks for the TIPS roles / tags [Guest] and [MAC Caching]. The enforcement profiles will be [H3C - Bounce Switch Port] and the endpoint update profile that you just created.

The **Default Profile** for the Enforcement Policy can be set to [H3C - Bounce Switch Port].




NOTE: In ClearPass 6.6.X and earlier, use the [Cisco - Bounce-Host-Port] enforcement profile.

ClearPass: Guest

Configuring a self-registration workflow in Guest is outside the scope of the document. For the purposes of this guide, the only relevant settings on the guest side are the **NAS Vendor Settings** and the **Login Delay**.



Under NAS Vendor Settings, be sure the Vendor Settings are set to Hewlett Packard Enterprise which should automatically set the Login Method to Server-initiated. This is what tells Guest to craft a WEBAUTH request which we just built the service for.



Under **Login Delay**, set the value to a minimum of 30 seconds. This is required with server-initiated workflows because we don't want the user to attempt to browse while the port is still down or their device is re-authenticating. You may need to adjust this value in your environment.



Useful Switch Troubleshooting Commands

display dot1x sessions
display dot1x sessions interface <interface>

```
<EDGE-5130EI>dis dot1x sessions
GigabitEthernet1/0/1 is link-down
   Online 802.1X users: 0
GigabitEthernet1/0/2 is link-down
   Online 802.1X users: 0
GigabitEthernet1/0/3 is link-up
  Online 802.1X users: 0
GigabitEthernet1/0/4 is link-down
  Online 802.1X users: 0
GigabitEthernet1/0/5 is link-down
  Online 802.1X users: 0
GigabitEthernet1/0/6 is link-up
   Online 802.1X users: 1
         MAC address
                           Auth state
         90e2-ba69-2d5a
                           Authenticated
GigabitEthernet1/0/7 is link-up
  Online 802.1X users: 0
GigabitEthernet1/0/8 is link-down
  Online 802.1X users: 0
```

```
display dot1x connection
display dot1x connection interface <interface>
display dot1x connection user-name <username>
display dot1x connection user-mac <MAC>
```

```
<EDGE-5130EI>display dot1x connection
Total connections: 1
Slot ID: 1
User MAC address: 90e2-ba69-2d5a
Access interface: GigabitEthernet1/0/6
Username: kylo.ren@timcappalli.com
Authentication domain: clearpass
IPv4 address: 100.81.1.12
Authentication method: EAP
Initial VLAN: 1
Authorization untagged VLAN: 811
Authorization tagged VLAN list: N/A
Authorization ACL ID: 3900
Authorization user profile: N/A
Authorization URL: N/A
Termination action: Radius-request
Session timeout period: 43200 s
Online from: 2017/04/03 02:05:30
Online duration: 0h 8m 12s
```

display mac-authentication interface <interface>

```
<EDGE-5130EI>dis mac-authentication interface GigabitEthernet 1/0/3
Global MAC authentication parameters:
  MAC authentication
                         User name format
          Username
                        : mac
          Password
                        : mac
  Offline detect period : 300 s
  Quiet period
                        : 60 s
                        : 100 s
  Server timeout
                        : 3600 s
  Reauth period
  Authentication domain : Not configured, use default domain
Max MAC-auth users
                        : 4294967295 per slot
Online MAC-auth users
                        : 1
GigabitEthernet1/0/3 is link-up
  MAC authentication
                            : Enabled
  Carry User-IP
                             : Disabled
  Authentication domain
                            : clearpass
  Auth-delay timer
                            : Enabled
  Auth-delay period
                            : 15 s
  Periodic reauth
                             : Enabled
  Reauth period
                            : N/A
  Re-auth server-unreachable : Online
  Guest VLAN
                            : Not configured
  Guest VLAN auth-period
                            : 30
                            : Not configured
  Critical VLAN
  Critical voice VLAN
                             : Disabled
  Host mode
                            : Multiple VLAN
  Offline detection
                            : Enabled
  Authentication order
                            : Parallel
  Max online users
                            : 10
  Authentication attempts
                            : successful 21, failed 0
  Current online users
                             : 1
         MAC address
                          Auth state
         2c41-387f-c880
                          Authenticated
```

```
display mac-authentication connection
display mac-authentication connection interface <interface>
display mac-authentication connection user-mac|user-name <MAC>|<username>
```

```
<EDGE-5130EI>dis mac-authentication connection interface GigabitEthernet 1/0/3
Total connections: 1
Slot ID: 1
User MAC address: 2c41-387f-c880
Access interface: GigabitEthernet1/0/3
Username: 2c41387fc880
Authentication domain: clearpass
Initial VLAN: 813
Authorization untagged VLAN: N/A
Authorization tagged VLAN: 813
Authorization ACL ID: 3900
Authorization user profile: N/A
Authorization URL: N/A
Termination action: Default
Session timeout period: N/A
Online from: 2017/04/03 01:42:42
Online duration: 0h 5m 56s
```

SNMP-based Enforcement

Policy Enforcement

VLAN assignment via SNMP is the primary enforcement method with OnConnect. VLAN access control lists (ACLs) are commonly used to control traffic in this scenario.

Configuration Overview

Here are the hardware and software combinations used for this configuration:

- HPE 5130El switch running code version 7.10.R3115P07 (no version dependency)
- ClearPass Policy Manager 6.7.1 (required: 6.7.1+)

This configuration example uses SNMP v2c. SNMPv3 is also supported for OnConnect.

Quirks and Limitations

- Active user visibility is available for Windows domain-joined machines only
- OnConnect enforcement takes an average of 60 seconds with WMI enabled

Switch Configuration

Global switch configuration:

snmp-agent	enable SNMP agent
snmp-agent community read C0mw@re!	define SNMP ro community for ClearPasss
snmp-agent community write C!earP@ss0nConn5ct	define SNMP rw community for ClearPass
snmp-agent target-host trap address udp-domain 100.65.30.52 params securityname C!earP@ss0nConn5ct v2c	set ClearPass as the snmp trap destination
<pre>snmp-agent trap enable mac-address snmp-agent trap enable arp snmp-agent trap if-mib link extended</pre>	enable SNMP traps

Interface configuration:

```
interface range GigabitEthernet 1/0/1 to
GigabitEthernet 1/0/12

port access vlan 2101


set default untrusted VLAN
```

ClearPass: Basics

Server Configuration

Configure the SNMP v2c Trap Community under Administration » Server Manager » Server Configuration, Service Parameters, ClearPass network services.

This should match the community string defined in this switch configuration element: snmp-server host 100.65.30.42 community ClearPassOnConnect trap-level all



After changing the trap community, the **System auxiliary services** service needs to be restarted.

Navigate to Administration » Server Manager » Server Configuration, Services Control and locate System auxiliary services.

Click Stop . Once the service has stopped, click Start to restart the service.

Network Device


Enable SNMP Read and configure the community strings for the device:



Enable SNMP Write and configure the community strings for the device. Also, configure the Default VLAN (generally this will be the guest or untrusted VLAN):



Enable Policy Manager to perform OnConnect Enforcement.



Use the **Query Ports** button to test the SNMP configuration. The list will be populated with the switch ports if all is working correctly.

Individual interfaces can also be enabled for OnConnect enforcement by selecting them in the list and clicking **Add to Port Names** (or by manually adding them to the Port Names list).

Windows Management Instrumentation (WMI) Overview


During a port status change, ClearPass can query domain-joined Windows devices for the current logged in user. This information can then be compared with user account information in Active Directory during authorization.

Requirements:

- Active Directory user account with WMI remote access privileges
- Windows firewall must allow inbound access to WMI from ClearPass

WMI Configuration: ClearPass

Inside ClearPass, map the WMI credentials to the edge subnets under **Configuration** » **Profile Settings** » **WMI Configuration**.




ClearPass: Enforcement Profiles

Enforcement profiles for OnConnect are very basic.

For each enforcement VLAN, create a new SNMP Based Enforcement profile. Navigate to **Configuration** » **Enforcement** » **Profiles** » **Add Enforcement Profile**. Select **SNMP Based Enforcement** from the template dropdown.

Add the **VLAN ID** and **Reset Connection** attributes. You can also optionally add the **Session Timeout** attribute to trigger a re-evaluation of policy after a certain amount of time.




ClearPass: OnConnect Service

Service Configuration

Start with a new service of type ClearPass OnConnect Enforcement.

Under More Options, check the **Authorization**. This will enable the Authorization tab. The default service rules will work with a Comware 7 switch.

If there is a need to restrict the service to a particular set of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS_TO_GROUP** service rule to reference a NAD group as seen in rule 2 below.



Authentication

Since OnConnect does not do any traditional user or device authentication, the only option available on the Authentication tab is the Strip Username Rules configuration.

If you are not planning to use WMI, nothing has to be configured on the Authentication tab.


If you are planning to use WMI to grab the currently logged in user, the Strip Username Rules will need to be configured. WMI returns the username in down-level logon format (REALM\username) so the REALM will need to be stripped off before an authorization check can be done against Active Directory.

Use the \:user rule to strip the REALM from the down-level logon username.



Authorization

On the Authorization tab, add the [Endpoints Repository] and [Guest Device Repository] to the "Additional authorization sources..." list as shown below. If WMI-based authorization will be used, also add your Active Directory authentication source to the list so user properties can be evaluated.



Roles


Role mapping is used to tag devices and users with as much information as possible for use in a policy decision

This *example* role map covers both headless devices and user mapping based off AD group membership. Headless devices are mapped using a mix of device registrations and raw profile data.



Enforcement

For the default policy, the default guest VLAN profile is specified. This is used when a request falls through the policy with no match. Let's take apart the enforcement policy, rule by rule.



(Tips:Role EQUALS USER_CONTRACTOR) SNMP_VLAN_2101

If the logged in user is a member of the "Contractor" AD group, the USER_CONTRACTOR tag/TIPS Role is mapped. This device is then given the GUEST VLAN, 2101 in this example.

2 (Authorization:AD_TIMCAPPALLI-COM_UPN:UserDN EXISTS) SNMP_VLAN_2102

This rule just checks that the logged in user is a domain user. All domain users will have a **UserDN** attribute. These devices will be placed into the "SECURE" VLAN, 2102 in this case.

(Authorization:[Endpoints Repository]:Category BELONGS_TO
VoIP Phone,Video Conferencing)

SNMP_VLAN_2103

Profile data is being leveraged in rule 3 to drop voice devices into VLAN 2103, for voice.

4 (Tips:Role MATCHES_ANY DEVICE_GAME-CONSOLE
DEVICE_MEDIA-PLAYER
DEVICE_PRINTER
DEVICE_ACCESS-POINT)
SNMP_VLAN_2104

These tags/TIPS roles are mapped based on the role assigned during Device Registration. These registered devices will be dropped into the "HEADLESS" VLAN, 2104 in this case.

Useful Troubleshooting Commands and Tips

ClearPass

If OnConnect requests are not appearing in Access Tracker, take a look in Event Viewer. Below are some common error messages.

• Traps are being sent by the switch, but the network device definition in ClearPass does not have the port listed for OnConnect enforcement.



• The SNMP trap community is mismatched



Switch

display snmp-agent trap-list

This command will give you a summary of the switch's SNMP trap configuration.

```
[CW-5130EI] dis snmp-agent trap-list
    arp notification is disabled.
    configuration notification is enabled.
    mac-address notification is enabled.
    radius notification is disabled.
    standard notification is enabled.
    stp notification is disabled.
    system notification is enabled.

Enabled notifications: 4; Disabled notifications: 3
```

debugging snmp agent packet receive debugging snmp trap packet

Debug commands can be used for more advanced troubleshooting and to verify that the switch is sending traps to ClearPass. Sample debug output is shown below.

Link change trap

```
%Feb 5 14:53:26:598 2018 CW-5130EI IFNET/5/LINK UPDOWN: Line protocol on the interface
GigabitEthernet1/0/2 is down.
*Feb 5 14:53:26:602 2018 CW-5130EI SNMP/7/TRAP_PACKET:
   linkDown trap<v2> send to: 100.65.30.52
   Request ID: 1954667472
   Error status: 0
Error index: 0
   UDP port: 162
   Trap successfully sent*Feb 5 14:53:26:603 2018 CW-5130EI SNMP/7/VBLIST:
   snmpTrapOID.0: 1.3.6.1.6.3.1.1.5.3
*Feb 5 14:53:26:603 2018 CW-5130EI SNMP/7/VBLIST:
   ifIndex.2: 2
*Feb 5 14:53:26:603 2018 CW-5130EI SNMP/7/VBLIST:
   ifAdminStatus.2: 2
*Feb 5 14:53:26:603 2018 CW-5130EI SNMP/7/VBLIST:
   ifOperStatus.2: 2
*Feb 5 14:53:26:603 2018 CW-5130EI SNMP/7/VBLIST:
   ifDescr.2: GigabitEthernet1/0/2
```

VLAN Enforcement and reset

```
*Feb 5 15:08:21:327 2018 CW-5130EI SNMP/7/PACKET:
    Set request
    Request ID: 1950334484
    Error status: 0
    Error index: 0
*Feb 5 15:08:21:327 2018 CW-5130EI SNMP/7/VBLIST:
    ifAdminStatus.1: 1
```

Cisco Catalyst (IOS) Enforcement

RADIUS-based Enforcement

Policy Enforcement

Access Control Lists (ACLs)

Cisco Catalyst switches can leverage two types of ACLs as part of policy enforcement.

Traditional ACLs are defined locally on the switch and can be returned as part of a RADIUS response or added directly to a switch port or VLAN interface.

Downloadable ACLs (dACLs) are defined centrally on the RADIUS server. When a client authenticates in this scenario, a dACL name is returned back to the switch. The switch then sends a second RADIUS request to pull down the contents of the dACL.

RADIUS	2c41387fc880	2c41387fc880	WIRED_CISCO_MAC- AUTH	ACCEPT	VLAN_EDGEGUEST- 300S, DACL_CISCO_DHCP-DNS	< Initial auth
RADIUS	#ACSACL#-IP- DACL_CISCO_DHCP_DNS 3001-2	-	Cisco Downloadable ACL	ACCEPT	DACL_CISCO_DHCP-DNS	< dACL request

VLAN Enforcement

A VLAN in Cisco IOS can be referenced by VLAN-ID or VLAN name. Although it is an optional configuration, VLAN name is highly recommended in a colorless port deployment as it removes the need for ClearPass to maintain a VLAN to function mapping for each switch. This simplifies policy creation, management and troubleshooting.

For example, each switch might use a different VLAN-ID for "secure access". Instead of having to write complex policy in ClearPass to return the correct VLAN-ID for each switch, we just give the appropriate VLAN-ID a name on each switch; "SECURE" for example. Now in your ClearPass policy, you simply return a VLAN enforcement with "SECURE" as the VLAN-ID and each switch will use the appropriate VLAN-ID mapped locally on the switch.

Dynamic Authorization

Cisco Catalyst switches support the following dynamic authorization commands:

- Terminate Session: traditional disconnect message; reinitializes authenticator state
- Bounce Host Port: bounces the port by disabling and re-enabling the port
- Disable Host Port: administratively disables the port
- Reauthenticate Host: initiates a re-authentication event

ClearPass includes all 4 of these dynamic authorization enforcement profiles in Policy Manager.

NOTE: The switch can be configured to ignore Bounce Host Port and Disable Host Port commands using the following commands:

authentication command bounce-port ignore authentication command disable-port ignore

Configuration Overview

Here are the hardware and software combinations used for this configuration:

- Cisco Catalyst 2960 switch running Cisco IOS 15.0(2)SE10a with LAN base image
- ClearPass Policy Manager 6.6.4 (there are no ClearPass version dependencies for this configuration)

This section covers Cisco's Identity Based Networking Services (IBNS) **version 1** configuration model. A future update to this document will add IBNS 2.

NOTE: IBNS 2 requires Catalyst 3850 or 3650 running IOS 15.2(1)E+ or IOS-XE 03.05.00E+, Catalyst C6500 running IOS 15.2(1)SY+, or Sup8E running IOS-XE 03.06.00E+

Quirks and Limitations

On older Cisco Catalyst switches, each port can have only one VLAN assignment except in the case of a client device connected behind a VoIP device (in that scenario, the VoIP device is tagged and the device behind it is untagged).

These limitations were removed for the following switches and versions and VLANs can be assigned by authentication session:

- Catalyst 2960X, IOS 15.2(2)E
- Catalyst 3850, IOS-XE 03.03.00SE
- Catalyst 3650, IOS-XE 03.03.00SE

Switch Configuration

The configuration snippets below assume that components like VLANs, uplinks, NTP and other basics have already been configured. Note that NTP is required as accurate time plays a critical role in network authentication.

Define the ClearPass server(s) as RADIUS server(s) and dynamic authorization client(s):

```
radius server CLEARPASS-PROD
  address ipv4 10.65.30.42 auth-port 1812 acct-port 1813
  key LOng&Compl5x$ecret!
!
aaa server radius dynamic-author
  client 10.65.30.42 server-key LOng&Compl5x$ecret!
  port 3799
  auth-type all
!
```

Enable AAA functions:

aaa new-model aaa session-id common	
ip device tracking	tracks client IPs (required for dACLs)
aaa authentication dot1x default group radius aaa authorization network default group radius aaa accounting dot1x default start-stop group radius	enable each of the AAA functions and map server group
dot1x system-auth-control	globally enable port-based access control
radius-server vsa send accounting radius-server vsa send authentication	send Cisco VSA in authentication and accounting messages
radius-server attribute 11 default direction in	accept IETF 'filter-id' to assign ACLs

Define access control entries:

```
ip access-list extended CLEARPASS-REDIRECT
deny ip any host 10.65.30.42
permit tcp any any eq www
permit tcp any any eq 443

ip access-list extended default_port_acl
permit icmp any any
```

permit udp any eq bootpc any eq bootps permit udp any any eq domain permit tcp any host 10.65.30.42 eq www permit tcp any host 10.65.30.42 eq 443 permit tcp any host 10.65.30.42 eq 6658 deny ip any any	
<pre>ip access-list extended ALLOWALL permit ip any any</pre>	allow all ACL used after successful authN/authZ

Configure end-user ports:

<pre>interface FastEthernet0/1 description COLORLESS-PORT</pre>	
switchport access vlan 111 switchport mode access	assign a dead-end VLAN as default (optional security recommendation)
switchport voice vlan 813	set the voice VLAN if using VoIP devices
ip access-group default_port_acl in	default ACL applied to the port
authentication host-mode multi-domain	support both voice and data device on same port
authentication order dot1x mab	set the authentication sequence
authentication priority dot1x mab	set the priority for auth methods
authentication port-control auto	enable authentication on port
authentication timer reauthenticate server	accept reauth-interval from ClearPass
mab	enable MAC Auth Bypass
dot1x pae authenticator	set the port as an authenticator
dot1x timeout tx-period 10	EAP Request-Identity waiting period
dot1x timeout supp-timeout 15	supplicant timeout period
dot1x max-reauth-req 1	number of additional times EAP Req-ID is sent

ClearPass: Basics


Define Switch(es)

In order for ClearPass to service RADIUS requests, switches need to be added to ClearPass as Network Devices.

They can be defined individually (security best practice) or they can be added by range or subnet. For example, in a layer 2 deployment, all switches may have a management address in the same subnet. If all switches share the same RADIUS (and TACACS+) shared secrets, the subnet can be defined instead of each switch individually. You can also define a smaller range.

To add network devices, navigate to **Configuration** » **Network** » **Devices** and click **Add**.

At a minimum, give the device (or subnet/range) a name, add the IP address, subnet with mask or range, define the RADIUS Shared Secret and select Cisco as the Vendor Name. CoA is automatically enabled.



ClearPass: MAC Authentication

Overview

The MAC Authentication service will handle headless devices like printers, phones, access points and others as well as provide the redirect URL for unknown devices to allow for a captive portal authentication. A mix of dACLs and filter-id-based enforcement will be used to show the different options.

In this scenario, we're leveraging the Guest Device Repository and Device Registration Portal to allow endusers and IT staff to register headless and non-802.1X capable devices. These devices can be assigned a role and account lifetime. Device Registration Portal configuration will not be covered.

Service Configuration

Start with a new service of type MAC Authentication.

Under More Options, check the **Authorization** and **Profile Endpoints** boxes. This will enable two new tabs. The default service rules will work with a Cisco switch.


If there is a need to restrict the service to a particular group of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS_TO_GROUP** rule to reference a NAD group as seen in rule 4 below.



Authentication

On the authentication tab, remove [MAC Auth] under Authentication Methods and add [Allow All MAC Auth].


For Authentication Sources, you'll add [Guest Device Repository] [Local SQL DB] and move it above [Endpoints Repository].



Authorization

On the Authorization tab, add the [Endpoints Repository], [Guest User Repository] and [Guest Device Repository] to the "Additional authorization sources..." list as shown below.

By default, authorization data is only fetched from the authentication source where the user/device was found.



So, for example, let's say a guest user's device is re-authenticating to the network within their account expiration window, you'll find the MAC address in the [Endpoints Repository] with some data like guest role and expiration time but we also want to check with ClearPass Guest to make sure an administrator hasn't disabled the account.

Roles

Role mapping is used to tag devices and users with as much prevalent information as possible for use in a policy decision.


This role map is an example of a typical MAC Authentication:



- Conditions 1 and 2 are checking to see that a guest user account is still valid and returning the [MAC Caching] tag / TIPS role
- Conditions 3-12 map user and device role IDs to tags / TIPS roles for use in policy
- Conditions 13-15 map profiling data to a tag / TIPS role for use in policy

Enforcement

Let's take apart this enforcement policy rule by rule:



(Authorization:[Endpoints Repository]:Conflict *EQUALS* true) [Deny Access Profile], API_SERVICE-NOW_PROFILE-CONFLICT

If a device's profiled category changes, ClearPass triggers the **Conflict** attribute.

If the **Conflict** attribute is true, deny access to the network and also initiate an API call over to ServiceNow to open a ticket.

Other options could include a captive portal redirect to notify the user, text message to the user, etc.

(Authorization:[Endpoints Repository]:Category NOT_EXISTS) VLAN_EDGE--GUEST-300S, DACL_CISCO_DHCP-DNS

This rule evaluates whether the profile Category exists for the authenticating endpoint.

If it does not exist, the device has not been profiled and a dACL and VLAN assignment are returned to the switch. The dACL allows both DHCP and DNS:

1. Radius:Cisco Cisco-IP-Downloadable-ACL = permit udp any any eq bootps permit udp any any eq domain

3

(Tips:Role EQUALS [Guest]) VLAN_EDGE--GUEST, DACL_CISCO_INTERNET-ONLY,
AND (Tips:Role EQUALS [MAC Caching]) IETF_USERNAME_ENDPOINT

During role mapping, it was calculated that the device should still be MAC cached based on its expiration and the user's account status.

The **EDGE_GUEST** VLAN, internet-only dACL and the guest's username will be returned to the switch.

4

```
(Endpoint:Guest Role ID EQUALS AD-User) VLAN_EDGE--GUEST, DACL_CISCO_INTERNET-ONLY,

AND (Tips:Role EQUALS [MAC Caching]) IETF_USERNAME_ENDPOINT
```

Like the previous rule, the **Guest Role ID** attribute is being checked for AD-User and the expiration time is being compared to the current time.

5

```
(Tips:Role MATCHES_ANY DEVICE_GAME-CONSOLE

DEVICE_MEDIA-PLAYER

DEVICE_PRINTER)

AND (Authorization:[Guest Device Repository]:Device Account Enabled VLAN_EDGE--HEADLESS, FILTER-ID_ALLOWALL

EQUALS true)

AND (Authorization:[Guest Device Repository]:Device Account Expired

EQUALS false)
```

Many headless devices have been registered via the Device Registration portal. This rule evaluates whether the authenticating device was registered as a game console, media player or printer and that the device account is enabled and hasn't expired.

The EDGE_HEADLESS VLAN is being returned along with Filter-ID = ALLOWALL which references the local ACL on the switch of the same name.

6

```
(Authorization:[Endpoints Repository]:Category BELONGS_TO VOIP CISCO_DEVICE-TRAFFIC-CLASS_VOICE, FILTER-ID_ALLOWALL Phone, Video Conferencing)
```

Based on profiling data, we're authorizing devices categorized as VoIP Phone and Video Conferencing by sending back a filter-id and device-traffic-class.

This **device-traffic-class=voice** attribute/value pair tells the switch that this device should be treated as a voice device. Since the port's host-mode is configured for multidomain, the switch will tag the voice VLAN configured on the port down to the voice device.

Туре	Name	Value
1. Radius: Cisco	Cisco-AVPair	= device-traffic-class=voice

(Authentication: MacAuth MATCHES_ANY NotApplicable, KnownClient, UnknownClient) VLAN_EDGE--GUEST-300S, CISCO_URL-REDIRECT_WIRED-SPLASH, DACL_CISCO_REDIRECT

The last rule is effectively a "catch all" which handles unknown devices.

Enforcement action #1 uses the url-redirect-acl Cisco-AVPair to tell the switch to use the local CLEARPASS-REDIRECT ACL to control which traffic is redirected the captive portal.

Action #2 provides the redirect URL to the switch using the **url-redirect** Cisco-AVPair. Notice that we added a variable to dynamically appended the client MAC address to the URL. This is required for many guest workflows.




The second enforcement profile returns a dACL to control access during this captive portal pre-authentication state. We need to allow DNS and DHCP as well as HTTP and HTTPS traffic so that the switch will redirect all web traffic to ClearPass.

Туре	Name	Value
1. Radius: Cisco	Cisco-IP-Downloadable-ACL	permit tcp any any eq www permit tcp any any eq 443 = permit udp any any eq domain permit udp any any eq bootps deny ip any any

Profiler

The Profiler function allows for an unknown device to be automatically disconnected from the network once profile data has been collected and evaluated. This prevents a device from being "stuck" in a limited access role. During the second authentication, the new profile data can be used in the policy decision. This is a very common feature for MAC Authentication services.

In this case, we want to bounce the port for any type of new device because of rule 2 in the enforcement policy. Since this is a Cisco switch, the RADIUS CoA Action is [Cisco - Bounce-Host-Port].



NOTE: Use caution in voice environments where client devices are connected behind a VoIP device. Bouncing a port after profiling a new device connected behind the VoIP device could result in interruption of voice service.

ClearPass: 802.1X

Service Configuration

Create a new service of type 802.1X Wired.

Under More Options, check the **Authorization** boxes. The default service rules will work with a Cisco switch.

If there is a need to restrict the service to a particular group of switches, you can use a Connection | NAD-IP-Address | BELONGS_TO_GROUP rule to reference a NAD group as seen in rule 3 below.



Authentication

This service will be supporting both secure certificate-based authentication (EAP-TLS) and traditional, legacy username and password authentication (PEAPv0/EAP-MSCHAPv2).

The username and password based authentication will be used for two purposes:


- 3) Allow a BYOD device to initially connect and kick off the Onboard process to issue them a certificate
- 4) Allow for domain-joined assets to use their computer/machine account to authenticate to the network as well as support machine + user workflows

Based on the above requirements, remove all the default EAP methods from the Authentication Methods list on the Authentication tab except for [EAP PEAP] and [EAP TLS].

NOTE: The default **[EAP TLS]** method does not have OCSP authorization configured. OCSP is used to check real-time validity of a certificate and enabling it is highly recommended. Special care should be taken when authenticating certificates from different certificate authorities. This is outside the scope of this document.


For Authentication Sources, you'll add our Active Directory identity store and also the **[Local User Repository]**. Authentication sources will vary in your environment.

The Local User Repository will be used in the example for infrastructure accounts like having an access point or VoIP phone authenticate securely to the network using the 802.1X framework.



Authorization


Since device profile information will be leveraged in policy, add the [Endpoints Repository] to the "Additional authorization sources..." list as shown below.



Roles

Role mapping is used to tag devices and users with as much prevalent information as possible for use in a policy decision.

These rules and tags will vary greatly by environment, but below you'll find examples of device and user tagging.



- Rules 1 and 4 are checking group membership from Active Directory
- Rules 2-3 are matching on the common name of the issuing CA for the authenticating certificate

Enforcement

Let's take apart this enforcement policy rule by rule:



(Tips:Role EQUALS [User Authenticated]) VLAN_EDGE--SECURE, FILTER-ID_ALLOWALL

AND (Tips:Role EQUALS [Machine Authenticated])

When a Windows device authenticates to the network using its Active Directory computer account, the [Machine Authenticated] tag/TIPS role is added to the session automatically.

If both a machine and user authentication have occurred, then return the **EDGE_SECURE** VLAN and the **allowall** filter-ID.

This is commonly used to validate that the user is connecting from a corporate asset.

(Tips:Role EQUALS [Machine Authenticated]) VLAN_EDGE--SECURE, FILTER-ID_ALLOWALL

Rule 2 is for a machine-only authentication. These typically occur when the device is sitting at the Windows logon screen and connectivity is required for updates, remote access or for new users to login.

3

```
(Tips:Role EQUALS [User Authenticated])

AND (Endpoint:MDM Enabled EQUALS true)

AND (Endpoint:Compromised EQUALS false)

AND (Tips:Role EQUALS CERT_CORP-DEVICE-CA)

VLAN_EDGE--SECURE, FILTER-ID_ALLOWALL
```

This is a typical rule to deal with a non-Windows corporate-managed asset that is managed by an EMM solution.

The two endpoint attributes have been synced down from the EMM solution. In this case, the rule is evaluating whether the device has its device management enabled and that no compromise has occurred.

The last condition checks for the tag/TIPS role from our role mapping to verify the certificate used to authenticate was issued from the Corporate Device CA.

4

(Authentication:OuterMethod EQUALS EAP-PEAP)	VLAN_EDGEGUEST, CISCO_URL-REDIRECT_ONBOARD,
AND (Tips:Role EQUALS USER_ONBOARD-REQ)	DACL_CISCO_REDIRECT

Most personal devices will perform Onboarding through the captive portal workflow after 802.1X fails, but some users may authenticate via PEAPv0/EAP-MSCHAPv2 when prompted by their device.

This rule will catch those users who need to be using EAP-TLS authentication via ClearPass Onboard.

Enforcement action #1 returns the EDGE_GUEST VLAN name.

Enforcement action #2 uses the **url-redirect-acl** Cisco-AVPair to tell the switch to use the local **CLEARPASS-REDIRECT** ACL to control which traffic is redirected the captive portal.

Rule number 2 provides the redirect URL to the switch using the **url-redirect** Cisco-AVPair. Notice that we added a variable to dynamically appended the client MAC address to the URL.



Enforcement action #3 returns a dACL to control access during this captive portal preauthentication state. DNS and DHCP as well as HTTP and HTTPS traffic need to be allowed so that the switch will redirect all web traffic to ClearPass.

Туре	Name	Value
1. Radius: Cisco	Cisco-IP-Downloadable-ACL	permit tcp any any eq www permit tcp any any eq 443 = permit udp any any eq domain permit udp any any eq bootps deny ip any any

(Tips:Role EQUALS USER_LIMITED-ACCESS)

VLAN_EDGE--GUEST, FILTER-ID_INTERNET-ONLY

This is a basic rule as an example of a security exception for a group of users. These devices are dropped into the **EDGE_GUEST** VLAN with the **INTERNET-ONLY** ACL.

(Tips:Role EQUALS [User Authenticated])

AND (Tips:Role EQUALS CERT_ONBOARD-BYOD-CA)

VLAN_EDGE--SECURE, FILTER-ID_BYOD

After a device has been Onboarded, it will authenticate via EAP-TLS. Rule 6 uses the tag from the role mapping to check the common name of the issuing CA. These devices will be dropped into the **EDGE_SECURE** VLAN with the **BYOD** ACL.

7

(Authorization:[Endpoints Repository]:Category <u>EQUALS</u> Printer)

AND (Authorization:[Endpoints Repository]:Conflict <u>EQUALS</u> false)

VLAN_EDGE--HEADLESS, FILTER-ID_ALLOWALL

This rule uses the device category of Printer combined with a check of the Conflict flag. The authentication method (username/password vs certificate) does not really matter in this case, however, an additional condition could easily be added similar to rules 8 and 9 below.

8

(Authorization:[Endpoints Repository]:Category BELONGS_TO
VoIP Phone, Video Conferencing)

AND (Authorization:[Endpoints Repository]:Conflict EQUALS false)

AND (Certificate:Subject-DN EQUALS CN=Wired Phones,OU=PKI

Authority,O=Alcatel-Lucent,C=FR)

AND (Certificate:Issuer-DN EQUALS Alcatel Enterprise

Solutions,OU=PKI Authority,O=Alcatel,C=FR)

CISCO_DEVICE-TRAFFIC-CLASS_VOICE, FILTER-ID_ALLOWALL

Solutions,OU=PKI Authority,O=Alcatel,C=FR)

Many voice devices come from the factory with an embedded certificate that can be used for network authentication. The factory cert is being leveraged for EAP-TLS combined with profiling data. The **device-traffic-class=voice** Cisco-AVPair and **allowall** filter-id are being passed back.

This **device-traffic-class=voice** attribute/value pair tells the switch that this device should be treated as a voice device. Since the port's host-mode is configured for multidomain, the switch will tag the voice VLAN configured on the port down to the voice device.

Туре	Name	Value
1. Radius: Cisco	Cisco-AVPair	= device-traffic-class=voice

9

(Tips:Role EQUALS DEVICE_ACCESS-POINT)

AND (Authorization:[Endpoints Repository]:Category EQUALS Access
Points)

AND (Authorization:[Endpoints Repository]:Conflict EQUALS false)

AND (Authorization:Source EQUALS [Local User Repository])

As discussed during the authentication section, a local user account was created in ClearPass for use by access points to authenticate. Rule 9 is comparing the tag/TIPS role, category, conflict status and verifying the authentication source was the [Local User Repository]

ClearPass: Web Authentication

The Web Authentication service handles captive portal-based authentications with server-initiated workflows.


Service Configuration

Create a new service of type Web-based Authentication.

Check the Authorization box and select Matches ALL under Service Rule.

Add a second service rule with **Application:ClearPass** | **Page-Name** | **EQUALS** and then the page name.

For example: if the full page URL is https://<fqdn>/guest/wired_cisco_self-reg.php, then the page name is: wired_cisco_self-reg.



NOTE: The Page-Name attribute was added in ClearPass 6.7.0. Skip if using ClearPass 6.6.X.

Authentication


This service will be supporting both guest and Active Directory users for captive portal login.

For Authentication Sources, you'll add the [Guest User Repository] and also our Active Directory identity store. Authentication sources will vary in your environment.



Authorization

We will need to assign a manual expiration time to AD users. This time is calculated by the [Time Source] so it will need to be added as an additional authorization source.



Roles

In this scenario, guests and contractors will go through a standard self-registration process and any employee who authenticates with their corporate credentials will get a temporary guest role. Since there is no specific mapping of AD group, you'll use the [Guest Roles] role map.

If different enforcement actions will be taken for different groups or classifications of users, create a new role map like the in 802.1X configuration.



Enforcement

Because the server-initiated workflow is used with Cisco switching, the enforcement policy for the WEBAUTH service is very simple. The goal is to update the device endpoint record with attributes from the user authentication that will be stored and used for subsequent authentications and then bounce the port to trigger a reauthentication event. Note that if a VLAN change is not required, a re-authenticate session CoA can be used instead.


In this example, we're authenticating both guest and Active Directory accounts.

For the guest accounts, we need to set up a basic enforcement profile for MAC caching the user so when they re-authenticate after the port bounce, the user will not be prompted to authenticate again until their account expires.

Create a new enforcement profile for the guest users (Configuration » Enforcement » Profiles » Add Enforcement Profile).


- Select ClearPass Entity Update Enforcement from the Template dropdown
- Give the profile a name
- On the attributes tab, add the 3 entries below and then save
- Note that the value field will require manual entry (copy and paste the values below)

TYPE	NAME	VALUE
Endpoint	Username	%{Authentication:Username}
Endpoint	Guest Role ID	%{GuestUser:Role ID}
Endpoint	MAC-Auth Expiry	%{Authorization:[Guest User Repository]:ExpireTime}




Next, create an enforcement profile for the AD users following a similar process. Since captive portal-based access should only be temporary for employees, you'll use a manual expiration of one day by using [Time Source], a pre-built information source. (Configuration » Authentication » Sources » [Time Source]).

TYPE	NAME	VALUE
Endpoint	Username	%{Authentication:Username}
Endpoint	Guest Role ID	AD-User
Endpoint	MAC-Auth Expiry	%{Authorization:[Time Source]:One Day DT}



The enforcement policy is very basic. The first rule checks for a TIPS role / tag of [Guest].

The second rule checks that the Authentication Source is Active Directory and then issues a CoA bounce port and the endpoint update enforcement profile that was created.



Wired Policy Enforcement Solution Guide

ClearPass: Guest

Configuring a self-registration workflow in Guest is outside the scope of the document. For the purposes of this guide, the only relevant settings on the guest side are the **NAS Vendor Settings** and the **Login Delay**.



Under NAS Vendor Settings, be sure the Vendor Settings are set to Cisco Systems which should automatically set the Login Method to Server-initiated. This is what tells Guest to craft a WEBAUTH request which we just built the service for.



Under **Login Delay**, set the value to a minimum of 30 seconds. This is required with server-initiated workflows because we don't want the user to attempt to browse while the port is still down or their device is re-authenticating. You may need to adjust this value in your environment.



Useful Switch Troubleshooting Commands

show authentication sessions

```
EDGE-C2960#show authentication sessions
Interface MAC Address
                           Method
                                    Domain
                                              Status
                                                             Session ID
Fa0/4
           0015.177b.b0d7
                           dot1x
                                    DATA
                                              Authz Success
                                                             6451000D0000010569EC4085
                                    DATA
                                              Authz Success
                                                             6451000D0000010469E9CAC0
Fa0/1
           90e2.ba69.2d5a
                           mab
Fa0/5
           0004.f21e.f64a
                                    VOICE
                                              Authz Success
                                                             6451000D0000010669EF6C3F
```

show authentication sessions interface <x>

```
EDGE-C2960#show authentication sessions interface fastEthernet 0/1
            Interface: FastEthernet0/1
          MAC Address: 90e2.ba69.2d5a
IP Address: 100.81.2.10
            User-Name:
                        90e2ba692d5a
               Status:
                        Authz Success
                        DATA
               Domain:
       Oper host mode:
                        multi-domain
     Oper control dir:
                        both
        Authorized By:
                        Authentication Server
          Vlan Policy:
                        812
              ACS ACL:
                        xACSACLx-IP-DACL_CISCO_REDIRECT-3007-5
     URL Redirect ACL:
                        CLEARPASS-REDIRECT
         URL Redirect:
                        https://clearpass-
demo.arubaboston.com/guest/wired_cisco_self-reg.php?mac=90:e2:ba:69:2d:5a
      Session timeout: N/A
         Idle timeout:
                        N/A
    Common Session ID:
                        6451000D0000010469E9CAC0
      Acct Session ID:
                        0x00000139
                        0x54000105
               Handle:
Runnable methods list:
       Method
               State
       dot1x
                Failed over
                Authc Success
       mab
```

show dot1x interface <x> details

```
EDGE-C2960#show dot1x interface fastEthernet 0/4 details
Dot1x Info for FastEthernet0/4
PAE
                          = AUTHENTICATOR
QuietPeriod
                          = 60
ServerTimeout
                          = 0
SuppTimeout
                          = 15
ReAuthMax
                          = 1
MaxReq
                          = 2
TxPeriod
                          = 10
Dot1x Authenticator Client List
EAP Method
                         = (25)
Supplicant
                          = 0015.177b.b0d7
    sion ID = 6451000D0000010569EC4085
Auth SM State = AUTHENTICATED
Session ID
    Auth BEND SM State = IDLE
```

show epm session interface <x>

show ip device tracking all

```
EDGE-C2960#show ip device tracking all
IP Device Tracking = Enabled
IP Device Tracking Probe Count = 3
IP Device Tracking Probe Interval = 30
IP Device Tracking Probe Delay Interval = 0
                   MAC Address Vlan Interface
  IP Address
                                                                         STATE
100.81.2.13
                  90e2.ba69.2d5a 812 FastEthernet0/5
                                                                        INACTIVE
                  0004.f21e.f64a 813
100.81.3.10
                                           FastEthernet0/5
                                                                        ACTIVE
                   90e2.ba69.2d5a 812 FastEthernet0/1
                                                                        INACTIVE
100.81.2.10
                   2c41.387f.c880 812 FastEthernet0/2
100.81.2.10
                                                                        INACTIVE
                  90e2.ba69.2d5a 811 FastEthernet0/7
0015.177b.b0d7 811 FastEthernet0/4
                                                                         INACTIVE
100.81.1.10
100.81.1.11
                                                                        ACTIVE
Total number interfaces enabled: 8
Enabled interfaces:
   Fa0/1, Fa0/2, Fa0/3, Fa0/4, Fa0/5, Fa0/7, Fa0/9,
  Fa0/11
```

SNMP-based Enforcement

Policy Enforcement

VLAN assignment via SNMP is the primary enforcement method with OnConnect. VLAN access control lists (ACLs) are commonly used to control traffic in this scenario.

Configuration Overview

Here are the hardware and software combinations used for this configuration:

- Cisco Catalyst 2960 switch running Cisco IOS 15.0(2)SE10a with LAN base image
- ClearPass Policy Manager 6.6.4 (required: 6.6.1+)

Quirks and Limitations

- Active user visibility is available for Windows domain-joined machines only
- OnConnect enforcement takes an average of 60 seconds with WMI enabled

Switch Configuration

Global switch configuration:

snmp-server community OnC0nnect@Cisco2960RO! ro	create SNMP ro community for ClearPass
snmp-server community OnC0nnect@Cisco2960RW! rw	create SNMP rw community for ClearPass
snmp-server enable traps snmp linkdown linkup snmp-server enable traps mac-notification snmp-server enable traps entity snmp-server enable traps bridge newroot topologychange snmp-server enable traps vlan-membership	enable traps
<pre>snmp-server trap link ietf snmp-server trap timeout 5</pre>	trap settings
snmp-server host 100.65.30.42 trap version 2c Cle@rPassOnConnect! snmp mac-notification	set ClearPass as the snmp- server and set trap community
mac address-table notification change interval 1 mac address-table notification threshold mac address-table notification change	MAC notifications configuration

Interface configuration:


interface FastEthernet0/1	
switchport mode access switchport access vlan 10 switchport mode access	assign default VLAN and access mode
<pre>snmp trap mac-notification change added snmp trap mac-notification change removed</pre>	Enable MAC notifications

ClearPass: Basics

Server Configuration


Enable OnConnect under Server Configuration (Administration » Server Manager » Server Configuration)

NOTE: This is only required in ClearPass 6.6.X



Configure the SNMP v2c Trap community string for under **Administration** » **Server Manager** » **Server Configuration**, **Service Parameters**, **ClearPass network services**.

This should match the community string define in this switch configuration element: snmp-server host 100.65.30.42 trap version 2c Cle@rPassOnConnect! snmp mac-notification




After changing the trap community, the **System auxiliary services** service needs to be restarted.

Navigate to Administration » Server Manager » Server Configuration, Services Control and locate System auxiliary services.

Click Stop Once the service has stopped, click start to restart the service.

Network Device


Enable SNMP Read and configure the community strings for the device:



Enable SNMP Write and configure the community strings for the device:



Enable Policy Manager to perform OnConnect Enforcement.



Use the **Query Ports** button to test the SNMP configuration. The list will be populated with the switch ports if all is working correctly.

Individual interfaces can also be enabled for OnConnect enforcement by selecting them in the list and clicking **Add to Port Names** (or by manually adding them to the Port Names list).

Windows Management Instrumentation (WMI) Overview


During a port status change, ClearPass can query domain-joined Windows devices for the current logged in user. This information can then be compared with user account information in Active Directory during authorization.

Requirements:

- Active Directory user account with WMI remote access privileges
- Windows firewall must allow inbound access to WMI from ClearPass


WMI Configuration: ClearPass

Inside ClearPass, map the WMI credentials to the edge subnets under Configuration » Profile Settings » WMI Configuration.



WMI Configuration: ClearPass

Inside ClearPass, map the WMI credentials to the edge subnets under **Configuration** » **Profile Settings** » **WMI Configuration**.




ClearPass: Enforcement Profiles

Enforcement profiles for OnConnect are very basic.

For each enforcement VLAN, create a new SNMP Based Enforcement profile. Navigate to **Configuration** » **Enforcement** » **Profiles** » **Add Enforcement Profile**. Select **SNMP Based Enforcement** from the template dropdown.

Add the **VLAN ID** and **Reset Connection** attributes. You can also optionally add the **Session Timeout** attribute to trigger a re-evaluation of policy after a certain amount of time.




ClearPass: OnConnect Service

Service Configuration

Start with a new service of type **ClearPass OnConnect Enforcement**.

Under More Options, check the **Authorization**. This will enable the Authorization tab. The default service rules will work with an ArubaOS-Switch.

If there is a need to restrict the service to a particular set of switches, you can use a **Connection** | **NAD-IP-Address** | **BELONGS_TO_GROUP** service rule to reference a NAD group as seen in rule 2 below.




Authentication

Since OnConnect does not do any traditional user or device authentication, the only option available on the Authentication tab is the Strip Username Rules configuration.

If you are not planning to use WMI, nothing has to be configured on the Authentication tab.


If you are planning to use WMI to grab the currently logged in user, the Strip Username Rules will need to be configured. WMI returns the username in down-level logon format (REALM\username) so the REALM will need to be stripped off before an authorization check can be done against Active Directory.

Use the \:user rule to strip the REALM from the down-level logon username.



Authorization


On the Authorization tab, add the [Endpoints Repository] and [Guest Device Repository] to the "Additional authorization sources..." list as shown below. If WMI-based authorization will be used, also add your Active Directory authentication source to the list so user properties can be evaluated.



Roles

Role mapping is used to tag devices and users with as much information as possible for use in a policy decision.


This *example* role map covers both headless devices and user mapping based off AD group membership. Headless devices are mapped using a mix of device registrations and raw profile data.



Enforcement

For the default policy, the default guest VLAN profile is specified. This is used when a request falls through the policy with no match which would be a guest in this case.

Let's take apart the enforcement rules one by one:



(Tips:Role EQUALS USER_CONTRACTOR) SNMP_VLAN_812

If the logged in user is in the "Contractor" group, the USER_CONTRACTOR tag/TIPS Role is mapped. This device is then given the GUEST VLAN, 812 in this example.

2 (Authorization:AD_TIMCAPPALLI-COM_UPN:UserDN EXISTS) SNMP_VLAN_811

This rule just checks that the logged in user is a domain user. All domain users will have a UserDN attribute. These devices will be placed into the "SECURE" VLAN, 811 in this case.

(Authorization:[Endpoints Repository]:Category <u>BELONGS_TO</u> VoIP SNMP_VLAN_813

Profile data is being leverage in rule 3 to drop voice devices into VLAN 813, the voice VLAN.

4 (Tips:Role MATCHES_ANY DEVICE_GAME-CONSOLE
DEVICE_MEDIA-PLAYER
DEVICE_PRINTER
DEVICE_ACCESS-POINT)
SNMP_VLAN_815


These tags/TIPS roles are mapped based on the role assigned during Device Registration. These registered devices will be dropped into the "HEADLESS" VLAN, 815 in this case.

Useful Troubleshooting Commands and Tips

ClearPass

If OnConnect requests are not appearing in Access Tracker, take a look in Event Viewer. Below are some common error messages.

• Traps are being sent by the switch, but the network device definition in ClearPass does not have the port listed for OnConnect enforcement.



• The SNMP trap community is mismatched



Switch

debug snmp packets

Wired Policy Enforcement Solution Guide



www.arubanetworks.com 3333 Scott Blvd Santa Clara, CA 95054 Phone: 1-800-WIFI-LAN (+800-943-4526) Fax 408.227.4550

© 2018 Hewlett Packard Enterprise Development LP. All Rights Reserved.